

**COMPLEX SOLUTIONS
MADE SIMPLE**



DEEP SEA ELECTRONICS
DSE3000 Series PC configuration suite

057-087

Author : Anthony Manton



Deep Sea Electronics Plc
Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND

Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail : sales@Deepseapl.com
Website : www.deepseapl.com

DSE3000 Series configuration suite

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988. Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo and the names DSEUltra, DSEControl, DSEPower, DSEExtra, DSEMarine and DSENet are UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments

Issue	Comments
1	Initial release
1.1	Added "Power up in AUTO mode" item
2	Added phase to phase voltage display, oil pressure as PSI and AC systems. Module version V1.3

Typeface : The typeface used in this document is *Arial*. Care should be taken not to mistake the upper case letter l with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

TABLE OF CONTENTS

1	BIBLIOGRAPHY	4
2	DESCRIPTION	4
2.1	SOFTWARE INSTALLATION INSTRUCTIONS.....	5
3	HARDWARE INSTALLATION	8
3.1	TROUBLESHOOTING INSTALLATION.....	8
4	USING THE CONFIGURATION SUITE	9
5	MENUS AND TOOLBAR	10
5.1	FILE MENU	10
5.2	TOOLS MENU.....	11
5.2.1	UPDATE FIRMWARE	12
5.3	HELP MENU	14
5.4	TOOLBAR.....	14
6	EDIT CONFIG.....	15
6.1	SCREEN LAYOUT.....	15
6.2	MODULE	16
6.3	APPLICATION	16
6.4	INPUTS	17
6.4.1	DIGITAL INPUTS	18
6.4.2	INPUT FUNCTIONS.....	19
6.5	OUTPUTS	20
6.5.1	OUTPUT SOURCES.....	21
6.6	TIMERS.....	23
6.7	GENERATOR.....	24
6.7.1	GENERATOR OPTIONS.....	24
6.7.2	GENERATOR VOLTAGE	25
6.7.3	GENERATOR FREQUENCY	25
6.8	ENGINE.....	26
6.8.1	ENGINE OPTIONS.....	26
6.8.2	CRANK DISCONNECT	27
6.8.3	SPEED SETTINGS	28
6.9	ALTERNATIVE CONFIGURATION.....	28

1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which can be obtained from the DSE website www.deepseapl.com :

DSE PART	DESCRIPTION
057-004	Electronic Engines and DSE wiring
057-086	DSE3000 Series operator manual

The following third party documents are also referred to :

ISBN	DESCRIPTION
1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Published by Institute of Electrical and Electronics Engineers Inc

2 DESCRIPTION

The **Configuration Suite** allows supported DSE modules (such as the DSE3000 series) to be connected to a PC via USB A – USB B cable. Once connected the various operating parameters within the module can be viewed or edited as required by the engineer. This software allows easy controlled access to these values and also has diagnostic monitoring facilities.

The configuration suite should only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the panel / generating set to which it is fitted. Access to critical operational sequences and settings for use by qualified engineers, may be barred by a security code set by the generator provider.

The information contained in this manual should be read in conjunction with the information contained in the appropriate module documentation. This manual only details which settings are available and how they may be used.

A separate manual deals with the operation of the individual module (See section entitled *Bibliography* elsewhere in this document).

2.1 SOFTWARE INSTALLATION INSTRUCTIONS

Minimum system requirements

Operating System	Windows Vista, Windows XP or Windows 2000 with Microsoft™ .Net@ 2.0 framework
Monitor	17 inch recommended (1024 x 768 resolution)
Communications	USB required to configure the module.

<p>NOTE: - As the Configuration Suite software for Windows™ is a 32-Bit application requiring Microsoft .net 2 framework, it will not operate on Windows 2.0, 3.0, 3.1,3.11, 95, 98 or Me.</p> <p>NOTE: - Exit all other programs before installing the software. It is recommended that any earlier releases of the software be uninstalled prior to installing this version.</p> <p>NOTE: - Please register online at www.deepseapl.com – Once registered you will be able to download updates to the software to ensure that you always have access to the latest features.</p>
--


Insert the Software CD into the CD-ROM drive on the PC. The CD will then Auto-run if this feature is enabled on your PC.

Alternatively:


- Double click on **Computer**
- Double click on **CD-ROM Drive**
- Double click CDSetup




Click **Next** to continue





Select *Disk Cost* to view remaining disk space, Click **Next** to continue.



Example showing the *Disk Cost* window.





3 HARDWARE INSTALLATION

Ensure the Configuration Suite Software is installed on the PC as described above. The installation of the PC software also installs the DSE Controller USB Driver automatically. Connect the USB cable to the module and to the PCC using a Type A to Type B USB Cable.

Windows detects the module when power is applied to it.

You are now ready to configure or monitor the module using the Configuration Suite Software.



3.1 TROUBLESHOOTING INSTALLATION

Occasionally USB devices are disabled by the Windows operating system, the following procedure will re-enable the device in these instances.

- Disconnect the *Deep Sea Electronics Controller* from the USB port. Wait a moment, then reconnect and try again. If you still encounter problems then :
- Try another USB cable. If you don't have one, it's the same type of cable as usually used between a PC and a USB printer. If you still encounter problems then :
- Disconnect the *Deep Sea Electronics Controller*. Shutdown, then restart the PC. Reconnect the interface, then try again. If you continue to experience problems then :
- check the USB port with another device (for instance a mouse, printer or digital camera).


4 USING THE CONFIGURATION SUITE

To run the Configuration Suite Software for Windows program click the Windows start button


 or  depending upon your version of Windows.

Then select 'All Programs' - 'Deep Sea Electronics PLC' – "DSE Configuration Suite" – "DSE Configuration Suite"

After a short delay to load the application, the splash screen is shown...



...after which the screen will display:-



This is the initial start-up screen and can be disabled by checking the box *Hide this screen at start-up*. The screen prompts the user to select between the three main uses for the software:

- Creating a new configuration. Select the module type under *Create new configuration*. This allows you to create a configuration for the 'latest' module version. Use *File | Convert to...* to convert the configuration to suit an earlier module version or use *Tools | Update firmware* to update an 'earlier' module to the latest firmware version.
- Editing a configuration previously saved to disk or flash memory device. Select the configuration file either from the *Open recent configuration* area or by clicking *Open a configuration file* and browsing to the file.
- Reading and changing the configuration of a connected module. Click *Read configuration from a module*. The file is read from a currently connected DSE controller and is available for editing in the Configuration Suite.











Alternatively you can ignore this screen and continue to use the program in the background. Once you make a connection or load/create a configuration, the start-up screen will disappear.

5 MENUS AND TOOLBAR


The menu and toolbar are located at the top of the screen:



5.1 FILE MENU

 New	Create a new configuration file. You are prompted to select what kind of module you want to create the configuration for. The settings of the new configuration file match the factory settings for the chosen module type. You can only select to create a configuration file for the 'latest' version of controller. If you want to create a configuration for an earlier version of controller, you can use <i>Convert to...</i> to make your configuration suitable for the earlier controller or use <i>Tools Update firmware</i> to update the earlier module to the latest version.
 Open	Open an existing file from disk or flash memory device.
 Close	Close the currently open file.
 Save	Save the currently open file to the location it was loaded from previously. If this is a new file, you are prompted to enter a filename.
 Save As..	Save the currently open file, under a new name. You will be prompted to enter a filename.
 Write to module	Send the currently open configuration settings to the controller.
 Read from module	Read the settings out of the connected controller for viewing / editing.
Import from module	Read the settings from the connected DSE controller and convert to the currently selected configuration type.
Import from file	Read the settings from a DSE configuration file on disk or flash memory device and convert to the currently selected configuration type.
Convert to... ▶	Convert the currently loaded configuration file to suit another module type or another module version.
 Print	Print the currently open configuration file.
 Print Preview	Preview what the configuration file will look like on the page after printing.
 Page Setup	Select printer type and printer settings.
Exit	Exit the software. If the currently open file has changed since it was last saved, you will be prompted to save it.

5.2 TOOLS MENU


<p>Options</p>	<p>Opens the <i>Settings</i> screen containing customisation options for the Configuration Suite.</p> 
<p>Update Firmware</p>	<p>Allows the user to update the firmware (internal software) of the 3000 Series controller. See overleaf for complete description of this function.</p>

5.2.1 UPDATE FIRMWARE


Selecting *Update Firmware* initiates the update wizard:

The image displays four sequential screenshots of the Firmware Update Wizard, each with a callout box providing instructions or warnings.


- Step 1: Welcome**
Title: Firmware Update Wizard (1 of 6)
Content: "Welcome", "This wizard will guide you through the firmware update process.", "Warning: Interrupting this process at any point may render the module inoperable."
Buttons: "< Back", "Next >"
Callout 1: "Click the **exit** button if you don't want to update your module."
Callout 2 (Hint): "Hint: Stopping the update process once it begins could leave the module inoperable! If this occurs, simply run the update wizard again and let it complete correctly."
Callout 3: "Click **next** to continue."
- Step 2: Power down**
Title: Firmware Update Wizard (2 of 6)
Content: "Power down", "Disconnect the module from power supply."
Buttons: "< Back", "Next >"
Callout 4: "Ensure the module's supply is removed, and then Click **next** to continue."
- Step 3: Connect USB**
Title: Firmware Update Wizard (3 of 6)
Content: "Connect USB", "Connect the USB cable between the module and PC."
Buttons: "< Back", "Next >"
Callout 5: "Connect the USB cable to the module and into your PC, then Click **next** to continue."
- Step 4: Select file**
Title: Firmware Update Wizard (4 of 6)
Content: "Select file", "Select firmware update file.", "File name:" followed by a text input field and a "Browse" button.
Buttons: "< Back", "Next >"
Callout 6: "Click to select the firmware update file."
Callout 7: "Then click **next** to continue."



Power up the module. It will be automatically detected and the update process will begin.




If the file you attempt to send to the module is not compatible with the currently connected module, the update cannot continue. In this example an attempt was made to send a 7210 firmware file to a 7220 module!



The update is now in progress and will take under one minute.

During this phase:

- DO NOT DISCONNECT THE USB CONNECTION
- DO NOT TURN OFF YOUR PC
- DO NOT REMOVE POWER FROM THE DSE CONTROLLER




The update is now complete.

The module will automatically restart with the updated firmware (internal software program).

It is now safe to disconnect the USB lead and power down the module or your PC.











Click **OK** to continue.

5.3 HELP MENU

 About	Shows the version number of the configuration suite
---	---

5.4 TOOLBAR

The toolbar contains the most used commands from the menus and is often a quicker way of accessing these commands.


	Create a new configuration file
	Open an existing file from disk or flash memory device
	Save the currently open file to the location it was loaded from previously. If this is a new file, you are prompted to enter a filename.
	Print the currently open configuration file
	Preview what the configuration file will look like on the page after printing.
	Send the currently open configuration settings to the controller
	Read the settings out of the connected controller for viewing / editing
	Shows the version number of the configuration suite
Connect via  USB	Select the communication method. The choices present are dependent upon your PC's configuration. The DSE3000 series support only connection by USB. To connect via USB directly to the controller, select <i>USB</i> : 

6 EDIT CONFIG

This menu allows module configuration, to change the function of Inputs, Outputs and LED's, system timers and level settings to suit a particular application.

The available items for configuration depend upon the type of module connected. This document details the configurable parameters of the DSE3000 Series controllers only. Configuration of other module is contained within their respective manual.

6.1 SCREEN LAYOUT



6.2 MODULE

This section allows the user to change the options related to the modules' operation.



Miscellaneous Options	
Lamp Test at Startup	<input type="checkbox"/> = Lamp test at startup is not enabled <input checked="" type="checkbox"/> = Illuminates all module LEDs at startup
Power Save Mode enable	<input type="checkbox"/> = Power Save Mode is not enabled <input checked="" type="checkbox"/> = Module is placed into low current power save mode after one minute of inactivity in STOP mode.
Protected Start Enabled	<input type="checkbox"/> = The engine is started when the Start Button is pressed. <input checked="" type="checkbox"/> = Manual mode is entered upon the first press of the Start Button. A further press is required to start the engine. This helps prevent inadvertent starting of the set by users pressing the button by mistake.
Power up in AUTO mode	<input type="checkbox"/> = The module enters STOP mode when DC power is first applied (normal operation) <input checked="" type="checkbox"/> = The module enters AUTO mode when DC power is first applied <div style="border: 2px solid black; padding: 5px; margin-top: 10px;"> CAUTION! (The set will start upon application of the DC supply if the remote start input is active and <i>Power up in AUTO mode</i> is selected) </div>
Display Oil pressure in PSI (CAN variant only) (V1.3+)	<input type="checkbox"/> = The module displays the oil pressure in bar <input checked="" type="checkbox"/> = The module displays the oil pressure in PSI (pounds per square inch)
Display voltages phase to phase (V1.3+)	<input type="checkbox"/> = The module displays the voltage as measured at its terminals. <input checked="" type="checkbox"/> = The module displays the measured voltage multiplied by 2 or by 'root 3' as required by the AC System selected.

6.3 APPLICATION

Application

ECU (ECM) Options

Engine Type: Generic J1939

Alternative Engine Speed:

CAN Data Fail Alarm

Action: Shutdown

Arming: From Safety On

Activation Delay: 0s

Allows selection of the Engine type being used (ie Conventional Diesel Engine, Gas Engine or Electronic Engine)

Instructs electronic engines to run a their 'alternative speed' (supported CAN engines only)

Configuration of the CAN data fail alarm, providing protection against the failure of the engine ECU data link.

6.4 INPUTS

The inputs page is subdivided into smaller sections.
Select the required section with the mouse.

Inputs

[Oil Pressure](#)

[Coolant Temperature](#)

[Digital Inputs](#)

Oil Pressure

Low Oil Pressure Alarms


Shutdown

Trip Bar  <Value>

Engine Temperature


High Coolant Temperature Alarm

Shutdown

Trip °C  198 °F

6.4.1 DIGITAL INPUTS

The *digital inputs* page is subdivided into smaller sections. Select the required section with the mouse.



Digital Input A

Function: Emergency Stop
Polarity: Open to Activate
Action: [Greyed out]
Arming: [Greyed out]

Digital Input B

Function: Remote Start On Load
Polarity: Close to Activate
Action: [Greyed out]
Arming: [Greyed out]

Digital Input C

Function: User Configured
Polarity: Close to Activate
Action: Warning
Arming: From Safety On

Configures when the input is active: Never, always, active from starting, active from the end of the safety timer

Input function. See section entitled *Input functions* for details of all available functions

As this example shows a *predefined* function, these parameters are *greyed out* as they are not applicable

Close or open to activate

Example of a user configured input

Select the type of alarm required. For details of these, see the section entitled *Alarm Types* elsewhere in this document.

6.4.2 INPUT FUNCTIONS

Where a digital input is NOT configured as “user configured”, a selection can be made from a list of predefined functions. The selections are as follows:

Under the scope of IEEE 37.2, *function numbers can also be used to represent functions in microprocessor devices and software programs*. Where the DSE input functions can be represented by IEEE 37.2, the function number is listed below.

Function	Description
User Configured	Allows the user to set how the inputs reacts when active (typically used to give an alarm signal to the controller from an external protection device).
Alternative Configuration	Used to instruct the module to use the settings in the ‘alternative’ configuration.
Coolant Temperature switch	This input is used to give a <i>Coolant Temperature High</i> shutdown from a digital normally open or closed switch.
Emergency Stop	Used to give a signal from the Emergency Stop switch to give immediate shutdown of the engine. It is also recommended that the emergency stop switch breaks the signal from the Fuel and Start outputs or ECU Power outputs as applicable.
External Panel Lock	Used to lock the module into the current operating mode (ie STOP or AUTO mode)
Low fuel level switch	A digital normally open or closed fuel level switch gives this input to trigger a warning alarm.
Oil Pressure Switch	A digital normally open or closed oil pressure switch gives this input.
Remote Start off load	If this input is active, operation will be similar to the ‘Remote Start on load’ function except that the generator will not be instructed to take the load. This function can be used where an engine only run is required e.g. for exercise.
Remote Start on load	When in auto mode, the module will perform the start sequence and transfer load to the generator. In Manual mode, the load will be transferred to the generator if the engine is already running, however in manual mode, this input will not generate start/stop requests of the engine.
Smoke limit IEEE 37.2 – 18 accelerating or decelerating device	This input instructs the module to give a <i>run at idle speed</i> command to the engine either via an output configured to <i>smoke limit</i> or by data commands when used with supported electronic engines.

6.5 OUTPUTS

The screenshot shows a configuration window titled "Digital Outputs". It contains a table with four rows, each representing an output (Output A, Output B, Output C, Output D). Each row has two columns: "Source" and "Polarity". The "Source" column contains dropdown menus with the following values: "CAN ECU Power", "CAN ECU Stop", "Close Gen Output", and "Common Alarm". The "Polarity" column contains dropdown menus with the value "Energise".

Callout 1 (top): "Select what the output is to be used to control" points to the Source column.

Callout 2 (right): "Select if the relay is to energise or de-energise upon activation of the source" points to the Polarity column.

Callout 3 (left): "These labels match the typical wiring diagram" points to the Output A, B, C, and D labels.

	Source	Polarity
Output A	CAN ECU Power	Energise
Output B	CAN ECU Stop	Energise
Output C	Close Gen Output	Energise
Output D	Common Alarm	Energise

6.5.1 OUTPUT SOURCES

Under the scope of IEEE 37.2, *function numbers can also be used to represent functions in microprocessor devices and software programs*. Where the DSE output functions can be represented by IEEE 37.2, the function number is listed below.

The outputs are in alphabetical order with the *parameter* first. For instance for overspeed output, it's listed as *Engine Overspeed*.

Output source	Activates...	Is not active....
Not Used	The output will not change state (Unused)	
CAN Data Fail	Becomes active when no CAN data is received from the ECU after the safety delay timer has expired	Inactive when: <ul style="list-style-type: none"> CAN data is being received The set is at rest During the starting sequence before the safety delay timer has expired
CAN ECU Warning	The engine ECU has indicated that a Warning alarm is present.	Inactive when no Warning alarm from the ECU is present
CAN ECU Shutdown	The engine ECU has indicated that a Shutdown alarm is present.	Inactive when no Shutdown alarm from the ECU is present
CAN ECU Power	Used to switch an external relay to power the CAN ECU. Exact timing of this output is dependent upon the type of the engine ECU	
CAN ECU Stop	Active when the DSE controller is requesting that the CAN ECU stops the engine.	
Close Generator IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the 3110 module selects the generator to be on load this control source will be active.	Inactive whenever the generator is not required to be on load
Close Generator Pulse IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the 3110 module selects the generator to be on load this control source will be active for the duration of the Breaker Close Pulse timer, after which it will become inactive again.	
Common Alarm	Active when one or more alarms (of any type) are active	The output is inactive when no alarms are present
Common Electrical Trip	Active when one or more <i>Electrical trip</i> alarms are active	The output is inactive when no electrical alarms are present
Common Shutdown	Active when one or more <i>Shutdown</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Warning	Active when one or more <i>Warning</i> alarms are active	The output is inactive when no warning alarms are present
Energise to Stop	Normally used to control an <i>Energise to Stop</i> solenoid, this output becomes active when the controller wants the set to stop running.	Becomes inactive a configurable amount of time after the set has stopped. This is the <i>ETS hold time</i> .
Fuel Relay	Becomes active when the controller requires the governor/fuel system to be active.	Becomes inactive whenever the set should be stopped, including between crank attempts, upon controlled stops and upon fault shutdowns.
Gas Choke On	Becomes active during starting for the duration of the Gas Choke timer. Normally used to choke a gas engine.	Inactive at all other times
Generator Available	Becomes active when the generator is available to take load.	Inactive when <ul style="list-style-type: none"> Loading voltage and loading frequency have not been reached After <i>electrical trip</i> alarm During the starting sequence before the end of the warning timer.

Output source	Activates...	Is not active...
Open Generator IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the 3110 module selects the generator to be off load this control source will be active.	Inactive whenever the generator is required to be on load
Open Generator Pulse IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the 3110 module selects the generator to be off load this control source will be active for the duration of the Breaker Open Pulse timer, after which it will become inactive again.	
Preheat during preheat timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The preheat timer has expired
Preheat until end of crank	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached <i>crank disconnect</i> conditions
Preheat Mode until end of safety timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached the end of the <i>safety delay</i> timer
Preheat Mode until end of warming timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> • The set is stopped • The set has reached the end of the <i>warming</i> timer
Smoke Limiting	Becomes active when the controller requests that the engine runs at idle speed. As an output, this can be used to give a signal to the <i>Idle input</i> of an engine speed governor (if available)	Becomes inactive when the controller requests that the engine runs at rated speed.
Start Relay IEEE 37.2 – 54 turning gear engaging device	Active when the controller requires the cranking of the engine.	

6.6 TIMERS

Many timers are associated with alarms. Where this occurs, the timer for the alarm is located on the same page as the alarm setting. Timers not associated with an alarm are located on the timers page.

Timers

Start Timers

Start Delay	5s	<input type="range"/>
Pre-heat	0s	<input type="range"/>
Smoke Limit	0s	<input type="range"/>
Smoke Limit Off	0s	<input type="range"/>
Warming Up Time	1s	<input type="range"/>

Stopping Timers

Return Delay	30s	<input type="range"/>
Cooling Time	1m	<input type="range"/>
ETS Solenoid Hold	0s	<input type="range"/>


Breaker

Breaker Trip Pulse	0.5s	<input type="range"/>
Breaker Close Pulse	0.5s	<input type="range"/>


Timer	Description
Start delay	Used to give a delay before starting in AUTO mode. This timer is activated upon a remote start signal being applied, or upon a start due to mains failure, scheduled run or any other <i>automatic</i> start. Typically this timer is applied to prevent starting upon fleeting remote start signals or short term mains failures.
Pre-heat	Give a 'pre start' time during which the <i>Preheat</i> output will become active (if configured)
Smoke limit	The amount of time that the engine will be requested to run at <i>idle</i> speed upon starting. This is typically used to limit emissions at startup.
Smoke limit off	This should be set to a little longer than the amount of time that the set takes to run up to rated speed after removal of the command to run at <i>idle</i> speed. If this time is too short, the set could be stopped due to <i>underspeed</i> failure. If the time is too long, <i>underspeed</i> protection is disabled until the <i>Smoke limit time off</i> time has expired.
Warming up time	The amount of time that the set will run BEFORE being allowed to take load. This is used to warm the engine to prevent excessive wear.
Return delay	A delay, used in auto mode only, that allows for short term removal of the request to stop the set before action is taken. This is usually used to ensure the set remains on load before accepting that the start request has been removed.
Cooling time	The amount of time that the set will be made to run OFF LOAD before being stopped. This is to allow the set to cool down and is particularly important for engines with turbo chargers.
ETS Solenoid hold	The amount of time the <i>Energise to stop</i> solenoid will be kept energised after the engine has come to rest. This is used to ensure the set has fully stopped before removal of the stop solenoid control signal.
Breaker close pulse	The amount of time that <i>Breaker Close Pulse</i> signals will be present when the request to close a breaker is given.
Breaker Trip pulse	The amount of time that <i>Breaker Open Pulse</i> signals will be present when the request to open a breaker is given.

6.7 GENERATOR

The *generator* page is subdivided into smaller sections. Select the required section with the mouse.



6.7.1 GENERATOR OPTIONS



Parameter	Description
Alternator fitted	<input type="checkbox"/> = There is no alternator in the system, it is an <i>engine only</i> application <input checked="" type="checkbox"/> = An alternator is fitted to the engine, it is a generator application.
Poles	The number of poles on the alternator
AC System (V1.3+)	Allows a number of AC systems to be catered for. Although the 3110 module has only a two-wire input, rated to 277V nominal (absolute maximum 305V), it is possible to use the module with different systems as long as the maximum rating is not exceeded. Selecting the AC system shows the connections required for that particular system, along with the relevant connection numbers on the controller.

6.7.2 GENERATOR VOLTAGE

Generator Voltage Alarms

Under Voltage Shutdown

Enable

184 v PhN ————— 184v PhN

Loading Voltage

207 v PhN ————— 207v PhN

Over Voltage Shutdown

Shutdown

277 v PhN ————— 277v PhN

Parameter	Description
Generator Under voltage	IEEE 37.2 - 27AC Undervoltage relay
Generator Over voltage	IEEE 37.2 - 59AC Overvoltage relay

6.7.3 GENERATOR FREQUENCY

Generator Frequency Alarms

Under Frequency Shutdown

Enable

40.0 Hz ————— 80.0 %

Loading Frequency

45.0 Hz ————— 90.0 %

Nominal Frequency

50.0 Hz —————

Over Frequency Shutdown


Enable

57.0 Hz ————— 114.0 %


Parameter	Description
Generator Under Frequency	IEEE 37.2 -81 Frequency relay
Generator Over Frequency	IEEE 37.2 -81 Frequency relay

6.8 ENGINE

The *engine* page is subdivided into smaller sections. Select the required section with the mouse.



6.8.1 ENGINE OPTIONS



The "Engine Options" configuration page is divided into three sections:

- ECU (ECM) Options:** Contains "Engine Type" (a dropdown menu set to "Generic J1939") and "Alternative Engine Speed" (a checkbox).
- Startup Options:** Contains "Start Attempts" (a numeric spinner set to 3).
- Charge Alternator Alarm:** Contains "Enable" (a checked checkbox) and "Trip" (a numeric spinner set to 6.0 VDC).

This item is not adjustable here, it's read only. To change this item, visit the *module* menu.

Click to enable or disable the option. The relevant values below will appear *greyed out* if the alarm is disabled.

6.8.2 CRANK DISCONNECT

Crank disconnect settings are used to detect when the set fires during the starting sequence. As the set is cranked, the first parameter that passes its *crank disconnect* setting will result in the cessation of the cranking signal.

Having more than one *crank disconnect* source allows for a much faster crank disconnect response leading to less wear on the engine and starter components, and provides added safety in case one source is lost, by a blown or tripped fuse for example.

The screenshot shows the 'Crank Disconnect' configuration window. It is divided into two main sections: 'Options' and 'Crank Disconnect'.

Options:

- Crank disconnect on oil pressure:** A checkbox that is currently unchecked. A callout bubble points to it with the text: "Click to enable or disable the option. The relevant values below will appear greyed out if the alarm is disabled."
- Check oil pressure prior to starting:** A checkbox that is checked. A callout bubble points to it with the text: "If check oil pressure prior to starting is enabled, the cranking will not be allowed if the oil pressure is not seen as being low. This used as a double check that the engine is stopped before the starter is engaged"

Crank Disconnect:

- Oil Pressure:** A numeric input field set to 2.00 Bar. To its right is a slider control.
- Generator Frequency:** A numeric input field set to 21.0 Hz. To its right is a slider control.
- Engine Speed:** A numeric input field set to 600 RPM. To its right is a slider control.

Callouts for the sliders:

- A callout bubble points to the Oil Pressure slider with the text: "Type the value or click the up and down arrows to change the settings"
- A callout bubble points to the Generator Frequency slider with the text: "Click and drag to change the setting."

6.8.3 SPEED SETTINGS

The screenshot shows the 'Speed Settings' configuration window. It is divided into two main sections: 'Under Speed Shutdown' and 'Over Speed Shutdown'.

- Under Speed Shutdown:** Contains an 'Enable' checkbox. Below it is a numerical input field set to '1200 RPM' with a slider control to its right.
- Over Speed Shutdown:** Contains a 'Trip' input field set to '1710 RPM' with a slider control to its right.

Callouts provide the following instructions:

- A callout pointing to the 'Enable' checkbox: "Click to enable or disable the option. The relevant values below will appear *greyed out* if the alarm is disabled."
- A callout pointing to the '1200 RPM' input field: "Type the value or click the up and down arrows to change the settings"
- A callout pointing to the slider for '1200 RPM': "Click and drag to change the setting."
- A callout pointing to the '1710 RPM' input field: "Overspeed shutdown cannot be disabled."

6.9 ALTERNATIVE CONFIGURATION

The Alternative Configuration is provided to allow the system designer to cater for different AC requirements utilising the same generator system. Typically this feature is used by Rental Set Manufacturers where the set is capable of being operated at (for instance) 120V 50Hz and 240V 50Hz using a selector switch, or by taking advantage of the "auto voltage sensing" option of the DSE3110 Series.

The screenshot shows a vertical menu titled 'Alternative Configuration'. It contains three items:

- [Configuration Options](#)
- [Generator](#)
- [Engine](#)

Alternative configuration options contain a subset of the main configuration. The adjustable parameters are not discussed here as they are identical to the main configuration options.