



DEEP SEA ELECTRONICS

DSE6110 MKII / DSE6120 MKII

Configuration Suite PC Software Manual

Document Number: 057-224

Author: Fady Atallah

DEEP SEA ELECTRONICS PLC

Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND



Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail : sales@Deepseapl.com
Website : www.deepseapl.com

DSE6110 MKII / DSE6120 MKII Configuration Suite PC Software Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo is a UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments List

Amd. No.	Comments
1	Initial release
2	Updated to add the version 2 firmware features of the DSE61xx MKII module.

Typeface: The typeface used in this document is *Arial*. Care must be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

TABLE OF CONTENTS

1	INTRODUCTION	6
1.1	BIBLIOGRAPHY	6
1.1.1	INSTALLATION INSTRUCTIONS	6
1.1.2	MANUALS	6
1.1.3	OTHER	6
1.1.4	GLOSSARY OF TERMS	6
1.2	INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE	7
2	EDITING THE CONFIGURATION	8
2.1	SCREEN LAYOUT	8
2.2	MODULE	9
2.2.1	MODULE OPTIONS	9
2.2.2	EVENT LOG	11
2.2.2.1	DISPLAY OPTIONS	11
2.2.2.2	LOGGING OPTIONS	11
2.2.3	DATA LOGGING	12
2.2.3.1	SETTINGS	12
2.2.3.2	CONFIGURATION	13
2.2.3.3	EXTERNAL TRIGGERS	13
2.2.3.4	LOGGING WINDOW	13
2.3	APPLICATION	15
2.4	INPUTS	17
2.4.1	ANALOGUE INPUT CONFIGURATION	17
2.4.2	FLEXIBLE SENSOR D	18
2.4.3	EDITING THE SENSOR CURVE	19
2.4.4	DIGITAL INPUTS	20
2.4.4.1	DIGITAL INPUTS	20
2.4.5	ANALOGUE INPUTS	21
2.4.6	INPUT FUNCTIONS	22
2.5	DIGITAL OUTPUTS	25
2.5.1	OUTPUT SOURCES	25
2.6	TIMERS	30
2.6.1	START TIMERS	30
2.6.2	LOAD / STOPPING TIMERS	31
2.6.3	MODULE TIMERS	32
2.7	GENERATOR	33
2.7.1	GENERATOR OPTIONS	33
2.7.2	GENERATOR VOLTAGE	34
2.7.2.1	UNDER VOLTAGE ALARMS	34
2.7.2.2	NOMINAL VOLTAGE	34
2.7.2.3	OVER VOLTAGE ALARM	35
2.7.3	GENERATOR FREQUENCY	36
2.7.3.1	UNDER FREQUENCY ALARMS	36
2.7.3.2	NOMINAL FREQUENCY	36
2.7.3.3	OVER FREQUENCY ALARMS	37
2.7.4	GENERATOR CURRENT	38
2.7.4.1	GENERATOR CURRENT OPTIONS	38
2.7.4.2	OVERCURRENT ALARM	39
2.7.4.3	GENERATOR RATING	41
2.7.4.4	OVERLOAD PROTECTION	41
2.7.5	LOW LOAD	42
2.7.6	MAINS	43
2.7.7	MAINS OPTIONS	43
2.7.8	MAINS ALARMS	44
2.8	ENGINE	45
2.8.1	OIL PRESSURE	45
2.8.2	COOLANT TEMPERATURE	46
2.8.3	FUEL LEVEL	47
2.8.4	DEF LEVEL	49
2.8.5	ENGINE OPTIONS	50
2.8.5.1	MISCELLANEOUS OPTIONS	50
2.8.5.2	STARTUP OPTIONS	51
2.8.5.3	PRE-HEAT	51
2.8.5.4	POST-HEAT	51

2.8.5.5	ECU (ECM) OPTIONS.....	52
2.8.6	ECU (ECM) ALARMS.....	54
2.8.6.1	ECU DATA FAIL.....	54
2.8.6.2	DM1 SIGNALS.....	55
2.8.6.3	ADVANCED.....	56
2.8.7	CRANK DISCONNECT.....	57
2.8.8	GAS ENGINE OPTIONS.....	57
2.8.9	SPEED SENSING.....	58
2.8.10	SPEED SETTINGS.....	58
2.8.10.1	UNDER SPEED.....	59
2.8.10.2	OVER SPEED.....	59
2.8.11	PLANT BATTERY.....	60
2.8.11.1	PLANT BATTERY VOLTAGE ALARMS.....	61
2.8.11.2	CHARGE ALTERNATOR ALARM.....	61
2.8.11.3	START ON LOW BATTERY.....	61
2.9	MAINTENANCE ALARM.....	62
2.10	SCHEDULER.....	63
2.11	DISPLAY STRINGS.....	64
2.11.1	SUPPORT STRINGS.....	64
2.11.2	USER DEFINED STRINGS.....	65
2.12	CONFIGURABLE CAN INSTRUMENTATION.....	66
2.12.1	RECEIVED INSTRUMENTATION (1-10).....	66
2.12.1.1	MESSAGE IDENTIFICATION.....	67
2.12.1.2	DATA STRUCTURE.....	67
2.12.1.3	DISPLAY.....	67
2.12.1.4	TEST.....	68
2.12.2	RECEIVED INSTRUMENTATION (11-30).....	68
2.12.3	TRANSMITTED INSTRUMENTATION.....	69
2.12.3.1	MESSAGE IDENTIFICATION.....	70
2.12.3.2	DATA STRUCTURE.....	70
2.12.3.3	MAPPING.....	71
2.12.3.4	TEST.....	71
2.12.4	CONFIGURABLE CAN INSTRUMENTATION EXPORT/IMPORT.....	71
2.13	ALTERNATIVE CONFIGURATION.....	72
2.13.1	ALTERNATIVE CONFIGURATION OPTIONS.....	72
2.13.2	ALTERNATIVE CONFIGURATION OPTIONS.....	73
2.14	EXPANSION.....	74
2.14.1	DSE2130 INPUT MODULES.....	75
2.14.1.1	DIGITAL INPUTS (A-D).....	75
2.14.1.2	ANALOGUE INPUTS (E-H).....	76
2.14.2	DSE2157 RELAY MODULES.....	77
2.14.3	DSE2548 LED EXPANSION.....	78
3	SCADA.....	79
3.1	MIMIC.....	80
3.2	LANGUAGES.....	81
3.3	DIGITAL INPUTS.....	81
3.4	DIGITAL OUTPUTS.....	81
3.5	MAINS.....	82
3.5.1	FREQUENCY, VOLTAGES AND CURRENT.....	82
3.5.2	POWER.....	83
3.6	GENERATOR.....	84
3.6.1	FREQUENCY, VOLTAGES AND CURRENT.....	84
3.6.2	POWER.....	85
3.7	ENGINE.....	86
3.8	FLEXIBLE SENSOR.....	87
3.9	CONFIGURABLE CAN INSTRUMENTATION.....	88
3.10	ALARMS.....	89
3.11	ENGINE ALARMS.....	90
3.11.1	CURRENT ENGINE ALARMS.....	90
3.11.2	PREVIOUS ENGINE ALARMS.....	90
3.12	STATUS.....	91
3.13	EVENT LOG.....	92
3.14	ENHANCED CANBUS.....	93
3.15	MAINTENANCE.....	94
3.15.1	RECALIBRATE TRANSDUCERS.....	94
3.15.2	EXPANSION CALIBRATION.....	95
3.15.3	HOURS RUN AND NUMBER OF STARTS.....	95

3.15.4	MAINTENANCE ALARM RESET	96
3.15.5	DPF REGENERATION.....	96
3.15.6	MODULE PIN.....	97
3.15.7	DATE AND TIME	98
3.15.8	ACCUMULATED INSTRUMENTATION	99
3.15.9	LCD CONTRAST	99
3.16	DATA LOG.....	100
3.17	EXPANSION.....	101
4	ALARM TYPES.....	102

1 INTRODUCTION

The **DSE Configuration Suite PC Software** allows the DSE6100 MKII modules to be connected to a PC via USB A –USB B cable. Once connected the various operating parameters within the module are viewed or edited as required by the engineer. This software allows easy controlled access to these values.

This manual details the configuration of the DSE6110 MKII / DSE6120 MKII series controllers.

A separate document covers the older DSE6110 and DSE6120 modules configuration.

The DSE Configuration Suite PC Software must only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the panel / generating set to which it is fitted. Access to critical operational sequences and settings for use by qualified engineers, may be barred by a security code set by the generator provider.

The information contained in this manual must be read in conjunction with the information contained in the appropriate module documentation. This manual only details which settings are available and how they may be used. A separate manual deals with the operation of the individual module (See section entitled *Bibliography* elsewhere in this document).

1.1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which is obtained from the DSE website www.deepseapl.com

1.1.1 INSTALLATION INSTRUCTIONS

DSE PART	DESCRIPTION
053-173	6110 MKII / 6120 MKII installation instructions sheet

1.1.2 MANUALS

DSE PART	DESCRIPTION
057-151	DSE Configuration Suite PC Software Installation & Operation Manual
057-004	Electronic Engines and DSE wiring
057-226	DSE6110 MKII / DSE6120 MKII Operator Manual
057-096	DSE6100 Software Manual

1.1.3 OTHER

The following third party documents are also referred to:

ISBN	DESCRIPTION
1-55937-879-4	IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Published by Institute of Electrical and Electronics Engineers Inc

1.1.4 GLOSSARY OF TERMS

Term	Description
DSE6100 MKII, DSE61xx MKII	All modules in the DSE61xx MKII range.
DSE6110 MKII	DSE6110 MKII module/controller
DSE6120 MKII	DSE6120 MKII module/controller
CAN	Controller Area Network Vehicle standard to allow digital devices to communicate to one another.
CT	Current Transformer An electrical device that takes a large AC current and scales it down by a fixed ratio to a smaller scale.

Continued over page...

Term	Description
DEF	Diesel Exhaust Fluid (AdBlue) A liquid used as a consumable in the SCR process to lower nitric oxide and nitrogen dioxide concentration in engine exhaust emissions.
DM1	Diagnostic Message 1 A DTC that is currently active on the engine ECU (ECM).
DM2	Diagnostic Message 2 A DTC that was previously active on the engine ECU (ECM) and has been stored in the ECU's (ECM) internal memory.
DPF	Diesel Particulate Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas.
DPTC	Diesel Particulate Temperature Controlled Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas which is temperature controlled.
DTC	Diagnostic Trouble Code The name for the entire fault code sent by an engine ECU (ECM).
ECU/ECM	Engine Control Unit/Management An electronic device that monitors engine parameters and regulates the fuelling.
FMI	Failure Mode Indicator A part of DTC that indicates the type of failure, e.g. high, low, open circuit etc.
GSM	Global System for Mobile communications. Cell phone technology used in most of the World.
HEST	High Exhaust System Temperature Initiates when DPF filter is full in conjunction with an extra fuel injector in the exhaust system to burn off accumulated diesel particulate matter or soot.
HMI	Human Machine Interface A device that provides a control and visualisation interface between a human and a process or machine.
IDMT	Inverse Definite Minimum Time
OC	Occurrence Count A part of DTC that indicates the number of times that failure has occurred.
PGN	Parameter Group Number A CAN address for a set of parameters that relate to the same topic and share the same transmission rate.
PLC	Programmable Logic Controller A programmable digital device used to create logic for a specific purpose.
SCADA	Supervisory Control And Data Acquisition A system that operates with coded signals over communication channels to provide control and monitoring of remote equipment
SCR	Selective Catalytic Reduction A process that uses DEF with the aid of a catalyst to convert nitric oxide and nitrogen dioxide into nitrogen and water to reduce engine exhaust emission.
SPN	Suspect Parameter Number A part of DTC that indicates what the failure is, e.g. oil pressure, coolant temperature, turbo pressure etc.



1.2 INSTALLATION AND USING THE DSE CONFIGURATION SUITE SOFTWARE

For information in regards to instating and using the DSE Configuration Suite Software please refer to DSE publication: **057-151 DSE Configuration Suite PC Software Installation & Operation Manual** which is found on our website: www.deepseapl.com

2 EDITING THE CONFIGURATION

This menu allows module configuration, to change the function of Inputs, Outputs and LED's, system timers and level settings to suit a particular application.

2.1 SCREEN LAYOUT




2.2 MODULE

The module section is subdivided into smaller sections.

Select the required section with the mouse.

This section allows the user to change the options related to the module itself.



2.2.1 MODULE OPTIONS

Module Options

Description

1

2

LCD Indicators

		LCD Description
1 Digital Input A	Lit	LCD Indicator 1
2 Common Warning	Lit	LCD Indicator 2
3 Common Shutdown	Lit	LCD Indicator 3

Miscellaneous Options

- Lamp test at power up
- Enable fast loading feature
- Maintenance Pin Protected Enable
- Enable sleep mode
- Enable manual fuel pump control
- Support right-to-left languages in module strings
- Enable Cool Down In Stop Mode
- Limit Audible Alarm Duration
- Enhanced Tier IV Home Screen
- Show Active DTC
- Show Inactive DTC

Allows the user to select the function of the modules user configurable LED indicators. For details of possible selections, please see section entitled *Output sources* elsewhere in this document.

Allows the user to create logo and text insert cards

Parameter	Description
Lamp Test At Power Up	<input type="checkbox"/> = Feature disabled <input checked="" type="checkbox"/> = The LEDs on the module's fascia all illuminate when the DC power is applied as a 'lamp test' feature.
Enable Fast Loading	<div style="border: 2px solid black; padding: 5px; margin-bottom: 5px;"> <p>NOTE: Enabling Fast Loading is only recommended where steps have been taken to ensure rapid start up of the engine is possible. (For example when fitted with engine heaters, electronic governors etc.)</p> </div> <input type="checkbox"/> = Normal Operation, the safety on timer is observed in full. This feature is useful if the module is to be used with some small engines where pre-mature termination of the delay timer leads to overspeed alarms on start up. <input checked="" type="checkbox"/> = The module terminates the safety on timer once all monitored parameters have reached their normal settings. This feature is useful if the module is to be used as a standby controller as it allows the generator to start and go on load in the shortest possible time.

Continued overleaf...

Parameter	Description
Maintenance PIN Protected Enable	<input type="checkbox"/> = PIN is not required to reset maintenance alarms through the front panel. <input checked="" type="checkbox"/> = Maintenance alarm reset through the front panel is PIN protected.
Enable Sleep Mode	<input type="checkbox"/> =Normal operation <input checked="" type="checkbox"/> = Module goes into sleep (low current) mode after 1m of inactivity in STOP mode. Press any button to 'wake' the module.
Enable Manual Fuel Pump Control	<input type="checkbox"/> =Normal operation <input checked="" type="checkbox"/> =Allows manual fuel pump control when the "fuel level" instrument is being viewed.
Support Right-To-Left Languages in Module Strings	Determines the direction of text input where supported (i.e. configurable input text) <input type="checkbox"/> =left to right language support <input checked="" type="checkbox"/> =right to left language support
Enable Cool Down in Stop Mode	<input type="checkbox"/> =Normal operation. Pressing the Stop button instantly opens the load switch and stops the generator. <input checked="" type="checkbox"/> =Alternative operation. Pressing the Stop button instantly opens the load switch and puts the generator into a cooling run. Pressing the Stop button again instantly stops the generator.
Limit Audible Alarm Duration	<input type="checkbox"/> = Normal operation, the configured <i>Audible Alarm</i> digital output is active when any alarm is active on the controller. The <i>Audible Alarm</i> digital output is inactive when the alarm is muted or reset. <input checked="" type="checkbox"/> = The configured <i>Audible Alarm</i> digital output is active when any alarm is active on the controller for the duration of the <i>Audible Alarm Duration</i> timer. The <i>Audible Alarm</i> digital output is inactive when the alarm is muted or reset or when the <i>Audible Alarm Duration</i> timer expires.
Enhanced Tier IV Home Screen	<input type="checkbox"/> = Normal operation, the module shows the default home screen <input checked="" type="checkbox"/> = The module's home screen is changed to show the Tier IV Lamps
Show Active DTC ECU / ECM Only	Enable this option to show the active ECU / ECM fault codes on the module display. (Active DTC are also called DM1 in J1939 ECU)
Show Inactive DTC ECU / ECM Only	Enable this option to show the in-active ECU (ECM) DTC on the module display. Inactive DTCs are the historical log of the ECU, where previous alarms have been cleared from the active DTC list. (Inactive DTC are called DM2 in J1939).

2.2.2 EVENT LOG

2.2.2.1 DISPLAY OPTIONS

The module display option allows the operator to choose between `Date and Time` or `Engine Hours` displayed on the screen.

2.2.2.2 LOGGING OPTIONS

The event log is configured to allow users to select which events are stored.

Event Log

Display Options

Module display Date and time Engine hours run

Logging Options

Log the following events to the event log

Power up Shutdown alarms
Mains fail Electrical trip alarms
Mains return Warning Alarms
Engine Starts Maintenance alarms
Engine Stops

Enable crank voltage event logging
Activation Delay 0 ms

Parameter	Description
Power Up	<input type="checkbox"/> = Power up events are not logged in the module's event log <input checked="" type="checkbox"/> = Power up events are logged when the DC Supply is applied to the module or whenever the module is rebooted
Mains Fail	<input type="checkbox"/> = The Mains Fail events are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Mains Failure events
Mains Return	<input type="checkbox"/> = The Mains Return events are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Mains Return events
Engine Starts	<input type="checkbox"/> = The Engine Start events are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Engine Start events
Engine Stops	<input type="checkbox"/> = The Engine Stop events are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Engine Stop events
Shutdown Alarms	<input type="checkbox"/> = The Shutdown Alarms are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Shutdown alarms
Electrical Trip Alarms	<input type="checkbox"/> = The Electrical Trip Alarms are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Electrical Trip alarms
Warning Alarms	<input type="checkbox"/> = The Warning Alarms are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Warning Alarms
Maintenance Alarms	<input type="checkbox"/> = The Maintenance Alarms are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the Maintenance alarms
Enable Crank Voltage Event Logging	<input type="checkbox"/> = <i>Pre-crank</i> and <i>Average</i> crank voltages are not logged in the module's event log <input checked="" type="checkbox"/> = Logs the <i>Pre-crank</i> and the <i>Average</i> voltages. The <i>Pre-crank</i> is the voltage before cranking, the <i>Average</i> is the average voltage of the <i>Pre-crank</i> and the voltage level after the <i>Activation Delay</i> time from cranking.
Activation Delay	The timer starts when the <i>Start Relay</i> is energised, the DC Voltage during Cranking is logged after this time, to calculate the <i>Average Crank Voltage</i> .

2.2.3 DATA LOGGING

The module holds a rolling log of up to four parameters in a memory buffer. The buffered log is saved to the *Data Logging* when any of the parameters exceed its configurable *Trigger* or on an *External Trigger* such as an alarm. The logged data contains the *Logging Window* for each of the four parameters, holding a *Pre-Trigger* and *Post-Trigger* log.

The module's *Data Logging* memory holds up to 35 blocks of memory, each block containing the *Logging Window* for the selected parameters.

The *Data Logging* is viewed using the *Data Log Viewer* application, which can be accessed from the DSE Configuration Suite software under the Tools menu.

2.2.3.1 SETTINGS

Parameter	Description
Only Log When Engine is Running	<input type="checkbox"/> = The module logs data regardless of engine running state. <input checked="" type="checkbox"/> = The module only logs data when the engine is running.
Keep Oldest Data	<input type="checkbox"/> = When the logging memory is full, the module overwrites the oldest data first with the new data. <input checked="" type="checkbox"/> = When the logging memory is full, the module stops recording new data.

Parameters are continued overleaf...

2.2.3.2 CONFIGURATION

Parameter	Description
Logged Data	Select the instrument required to be logged
Log Interval	Select the logging interval of the data
Trigger	Select when the instrument is logged compared to the configurable value of the slider

2.2.3.3 EXTERNAL TRIGGERS

Parameter	Description
Trigger	Select an external trigger to initiate a data log
Polarity	Select the polarity of the trigger. Energise: the data log is triggered when the configured trigger goes active. De-Energise: the data log is triggered when the configured trigger goes inactive

2.2.3.4 LOGGING WINDOW

Parameter	Description
Pre-Trigger	Shows the duration of time before the trigger, during which the data is logged.
Post-Trigger	Shows the duration of time after the trigger, during which the data is logged.
Logging Window	Shows the total duration of data logging time, combining the duration before and after the trigger.

Example 1

In the example below, the selected three parameters are logged when the *Generator Total Power* exceeds the set trip level of 150 kW.

The *Data Log* in the module contains the values of these three parameters for the duration of the *Logging Window*, that is 11 m 22 s before the *Generator Total Power* exceeded 150 kW and 11 m 23 s after that.

The screenshot displays a configuration interface with three main sections:

- Configuration:** A table with four rows. Row 1: Logged data 'Coolant/ Eng Temperature', Log Interval '1 second', Trigger 'Not Used', value '0 °C'. Row 2: Logged data 'Oil Pressure', Log Interval '1 second', Trigger 'Not Used', value '0.00 Bar'. Row 3: Logged data 'Generator Total Power', Log Interval '1 second', Trigger 'Is greater than', value '150 kW'. Row 4: Logged data '<Not Used>', Log Interval '1 second', Trigger 'Not Used', value '0'.
- External Triggers:** Four rows, each with a 'Trigger' dropdown set to 'Not Used' and a 'Polarity' dropdown set to 'Energise'.
- Logging Window:** A slider showing 'Pre-trigger' at '11m 22s' and 'Post-trigger' at '11m 23s', with a total 'Logging Window' of '22m 45s'.

Editing the Configuration

Example 2

In the example below, the selected four parameters are logged when a *Common Alarm* occurs on the controller. The *Data Log* in the module contains the values of these four parameters for the duration of the *Logging Window*, that is 17 m 4 s before the *Alarm* occurred.

The screenshot displays a configuration interface with three main sections: Configuration, External Triggers, and Logging Window.

Configuration

	Logged data	Log Interval	Trigger	Value	Unit
1	Coolant/ Eng Temperature	1 second	Not Used	0	°C
2	Oil Pressure	1 second	Not Used	0.00	Bar
3	Generator Total Power	1 second	Not Used	0	kW
4	Generator Frequency	1 second	Not Used	0.0	Hz

External Triggers

Trigger	Trigger	Polarity
Trigger 1	Common Alarm	Energise
Trigger 2	Not Used	Energise
Trigger 3	Not Used	Energise
Trigger 4	Not Used	Energise

Logging Window

Pre-trigger: 17m 4s

Post-trigger: 0m 0s

Logging Window: 17m 4s

2.3 APPLICATION

 **NOTE:** For further details and instructions on ECU options and connections, refer to DSE Publication: *057-004 Electronic Engines and DSE Controllers* which are found on our website: www.deepseapl.com

Application

ECU (ECM) Options

Engine Type Conventional Engine ▾

Enhanced J1939

Alternative Engine Speed

Protections

Coolant Level Protection Override

Parameter	Description
Engine Type	<p>Select the appropriate engine type</p> <p>Conventional Engine: Select this for a traditional (non ECU) engine, either Energise to Run or Energise to Stop.</p> <p>Conventional Gas Engine: Select this for a traditional (non ECU) engine and require Gas engine functionality. This enables control of configurable outputs for <i>Gas Choke and Gas Ignition</i> and instructs the module to follow the gas engine timers.</p> <p>Other Engines: The list of supported CAN (or Modbus) engines is constantly updated, check the DSE website at www.deepseapl.com for the latest version of Configuration Suite software.</p>
Enhanced J1939	<p><input type="checkbox"/> = The module reads 'Basic' instrumentation from the engine ECU and display (where supported by the engine) :</p> <ul style="list-style-type: none"> • Engine Speed • Oil Pressure • Engine Coolant Temperature • Hours Run <p><input checked="" type="checkbox"/> = The module reads and display an 'Enhanced' instrumentation list (where supported by the engine) :</p> <ul style="list-style-type: none"> • Engine Speed • Oil Pressure • Engine Coolant Temperature • Hours Run • Engine Oil Temperature • Exhaust Temperature • Fuel Pressure • Total Fuel used • Fuel Consumption • Inlet Manifold Temperature • Coolant Pressure • Turbo Pressure <p>Where an instrument is not supported by the engine ECU, the instrument is not displayed.</p> <p>DSE Reserve the right to change these lists in keeping with our policy of continual development.</p>


Parameters are continued overleaf...

Editing the Configuration


Parameter	Description
Alternative Engine Speed	<input type="checkbox"/> = The engine is instructed to run at its <i>Nominal Speed</i> as configured by the Engine Manufacturer. <input checked="" type="checkbox"/> = The engine is instructed to run at its <i>Alternative Speed</i> as configured by the Engine Manufacturer.
Coolant Level Protection Override	<input type="checkbox"/> = The Coolant Level Protection is read from the ECU and a Shutdown alarm triggers when the ECU activates this alarm <input checked="" type="checkbox"/> = The Coolant Level Protection is ignored when the ECU activates this alarm.

2.4 INPUTS

The *Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.4.1 ANALOGUE INPUT CONFIGURATION



Parameter	Description
Module To Measure Oil Pressure	(Available only when the module is configured for connection to a CAN engine.) <input type="checkbox"/> = The measurements are taken from the ECU. <input checked="" type="checkbox"/> = The module ignores the CAN measurement and uses the analogue sensor input.
Module To Measure Coolant Temperature	(Available only when the module is configured for connection to a CAN engine.) <input type="checkbox"/> = The measurements are taken from the ECU. <input checked="" type="checkbox"/> = The module ignores the CAN measurement and uses the analogue sensor input.
Analogue Input A	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>Inputs/Analogue Inputs</i> pages Not Used: The input is disabled Oil Sensor: Configured on the <i>Engine</i> pages
Analogue Input B	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Temperature Sensor: Configured on the <i>Engine</i> pages Not Used: The input is disabled
Analogue Input C	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Flexible Analogue : Configured on the <i>Inputs/Analogue Inputs</i> pages Fuel Sensor: Configured on the <i>Engine</i> pages Not Used: The input is disabled
Analogue Input D	Select what the analogue input is to be used for: Digital Input: Configured on the <i>Inputs/Digital Inputs</i> pages Flexible Analogue: Configured on the <i>Inputs/Analogue Inputs</i> pages Not Used: The input is disabled Oil Sensor: Configured on the <i>Engine</i> pages

2.4.2 FLEXIBLE SENSOR D

Analogue input D is configured for *Flexible Sensor*.

Parameter	Description
Sensor Type	Select the sensor type: Pressure: The input is configured as a pressure sensor Percentage: The input is configured as a percentage sensor Temperature: The input is configured as a temperature sensor
Input Type	Select the sensor curve from a pre-defined list or create a user-defined curve
Alarm Arming	Select when the input becomes active: Always: The input state is always monitored From Safety On: The state of the input is monitored from the end of the <i>Safety On Delay</i> timer From Starting: The state of the input is only monitored from engaging the crank
Low Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Alarm</i> is active when the measured quantity drops below the <i>Low Alarm</i> setting.
Low Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Pre-Alarm</i> is active when the measured quantity drops below the <i>Low Pre-Alarm</i> setting. The <i>Low Pre-Alarm</i> is automatically reset when the measured quantity rises above the configured <i>Low Pre-Alarm Return</i> level.
High Pre-Alarm Enable	<input type="checkbox"/> = The Pre-Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Pre-Alarm</i> is active when the measured quantity rises above the <i>High Pre-Alarm</i> setting. The <i>High Pre-Alarm</i> is automatically reset when the measured quantity falls below the configured <i>High Pre-Alarm Return</i> level.
High Alarm Enable	<input type="checkbox"/> = The Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Alarm</i> is active when the measured quantity rises above the <i>High Alarm</i> setting.

2.4.3 EDITING THE SENSOR CURVE

While the *DSE Configuration Suite* holds sensor specification for the most commonly used resistive sensors, occasionally it is required that the module be connected to a sensor not listed by the *configuration suite*. To aid this process, a sensor editor has been provided.

In this example, the closest match to the sensor in use is the VDO 10-180Ω fuel level sensor.

Click to edit the 'sensor curve'.

Click and drag the points on the graphs to change the settings

Click *Interpolate* then select two points as prompted to draw a straight line between them.

Use the mouse to select the graph point, then enter the value in the box or click up/down to change the value

Click CANCEL to ignore and lose any changes you have made

Click OK to accept the changes and return to the configuration editor

Click SAVE AS, you are prompted to name your curve....


Click OK to save the curve.

Any saved curves become selectable in the *Input Type* selection list.


Hint: Deleting, renaming or editing custom sensor curves that have been added is performed in the main menu, select *Tools | Curve Manager*.

2.4.4 DIGITAL INPUTS

The *Digital Inputs* section is subdivided into smaller sections. Select the required section with the mouse.



2.4.4.1 DIGITAL INPUTS



Parameter	Description
Function	Select the input function to activate when the relevant terminal is energised. See section entitled <i>Input functions</i> for details of all available functions
Polarity	Select the digital input polarity: Close to Activate: the input function is activated when the relevant terminal is connected. Open to Activate: the input function is activated when the relevant terminal is disconnected.
Action	Select the type of alarm required from the list: Electrical Trip Shutdown Warning For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
Arming	Select when the input becomes active: Always: The input state is always monitored Active From Safety On: The state of the input is monitored from the end of the <i>Safety On Delay</i> timer Active From Starting: The state of the input is only monitored from engaging the crank Never: The input is disabled
Activation Delay	This is used to give a delay on acceptance of the input. Useful for liquid level switches or to mask short term operations of the external switch device.

2.4.5 ANALOGUE INPUTS

Analogue Inputs A - C

Analogue Input A (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page


Analogue Input B (Digital)

Function	User Configured
Polarity	Close to Activate
Action	Shutdown
Arming	Never
LCD Display	
Activation Delay	0s

Example of an analogue input configured as digital.

Analogue Input C (Digital)

The Analogue Input is not configured as a Digital Input
To reconfigure, use the 'Analogue Input Configuration' page

The image shows a web-based configuration interface for analogue inputs. It is titled "Analogue Inputs A - C". There are three sections for "Analogue Input A (Digital)", "Analogue Input B (Digital)", and "Analogue Input C (Digital)". Each section has a header and a message: "The Analogue Input is not configured as a Digital Input. To reconfigure, use the 'Analogue Input Configuration' page". The "Analogue Input B (Digital)" section is expanded to show configuration options: "Function" (User Configured), "Polarity" (Close to Activate), "Action" (Shutdown), "Arming" (Never), "LCD Display" (empty field), and "Activation Delay" (0s with a slider). A callout bubble points to the "Function" dropdown menu with the text "Example of an analogue input configured as digital."



2.4.6 INPUT FUNCTIONS




Where a digital input is NOT configured as “user configured”, a selection is made from a list of predefined functions. The selections are as follows:




Under the scope of IEEE 37.2, *function numbers are also used to represent functions in microprocessor devices and software programs.* Where the DSE input functions are represented by IEEE 37.2, the function number is listed below.



= Only applicable to DSE6120 MKII AMF Modules

Function	Description
Alarm Mute	This input is used to silence the audible alarm from an external source, such as a remote mute switch.
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the generator.
Alternative Configuration	These inputs are used to instruct the module to follow the <i>alternative</i> configuration settings instead of the <i>main</i> configuration settings.
Auto Restore Inhibit  IEEE 37.2 - 3 checking or interlocking relay	In the event of a remote start/mains failure, the generator is instructed to start and take load. On removal of the remote start signal/mains return the module continues to run the generator on load until the <i>Auto Restore Inhibit</i> input is removed. This input allows the controller to be fitted as part of a system where the restoration to mains is controlled remotely or by an automated system.
Auto Start Inhibit IEEE 37.2 - 3 checking or interlocking relay	This input is used to provide an over-ride function to prevent the controller from starting the generator in the event of a remote start/mains out of limits condition occurring. If this input is active and a remote start signal/mains failure occurs the module does not give a start command to the generator. If this input signal is then removed, the controller operates as if a remote start/mains failure has occurred, starting and loading the generator. This function is used to give an ‘AND’ function so that a generator is only called to start if the mains fails and another condition exists which requires the generator to run. If the ‘Auto start Inhibit’ signal becomes active once more it is ignored until the module has returned the mains supply on load and shutdown. This input does not prevent starting of the engine in MANUAL mode.
Auxiliary Mains Fail 	The module monitors the incoming single or three phase supply for Over voltage, Under Voltage, Over Frequency or Under frequency. It may be required to monitor a different mains supply or some aspect of the incoming mains not monitored by the controller. If the devices providing this additional monitoring are connected to operate this input, the controller operates as if the incoming mains supply has fallen outside of limits, the generator is instructed to start and take the load. Removal of the input signal causes the module to act if the mains has returned to within limits providing that the mains sensing also indicates that the mains is within limits.
Coolant Temperature Switch	This input is used to give a <i>Coolant Temperature High</i> shutdown from a digital normally open or closed switch. It allows coolant temperature protection.
DPF Auto Regen Inhibit	This input is used to override the ECU function and prevent the automatic regeneration of the diesel particulate filter
DPF Force Regeneration	This input is used to override the ECU function and activate the regeneration of the diesel particulate filter
DPF Regeneration Interlock	This input is used to stop a manual regeneration from occurring
External Panel Lock	Locks the mode buttons on the module front fascia.
Generator Closed Auxiliary IEEE 37.2 - 3 Checking or Interlocking Relay	This input is used to provide feedback to allow the 7xxx to give true indication of the contactor or circuit breaker switching status. It must be connected to the generator load switching device auxiliary contact.

Function	Description
Generator Load Inhibit IEEE 37.2 - 52 AC Circuit Breaker	<p>NOTE: This input only operates to control the generator-switching device if the module load switching logic is attempting to load the generator. It does not control the generator switching device when the mains supply is on load.</p> <p>This input is used to prevent the module from loading the generator. If the generator is already on load, activating this input causes the module to unload the generator. Removing the input allows the generator to be loaded again.</p>
Inhibit Scheduled Run IEEE 37.2 - 3 Checking Or Interlocking Relay	This input is used to provide a mean of disabling a scheduled run.
Lamp Test	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LEDs illuminate.
Low Battery Run	This input is used to run the generator off load when the DSE module is in Auto mode, once the input is removed the engine keeps running for the <i>Engine Run Duration</i> time configured in the <i>Start On Low Battery</i> in the <i>Plant Battery</i> section, then it stops after the <i>Return Delay</i> .
Low Fuel Level Switch	Used to give a digital input function to provide a low fuel level alarm
Mains closed Auxiliary IEEE 37.2 - 3 Checking or interlocking relay 	This input is used to provide feedback to allow the module to give true indication of the contactor or circuit breaker switching status. It must be connected to the mains load switching device auxiliary contact. Incorrect application of this signal does not trigger an alarm condition, it is used solely for indication of the breaker status.
Mains Load Inhibit IEEE 37.2 - 3 Checking or Interlocking Relay 	<p>NOTE: This input only operates to control the mains switching device if the module load switching logic is attempting to load the mains. It does not control the mains switching device when the generator is on load.</p> <p>This input is used to prevent the module from loading the mains supply. If the mains supply is already on load activating this input causes the module to unload the mains supply. Removing the input allows the mains to be loaded again.</p>
Manual Restore contact IEEE 37.2 - 3 Checking or Interlocking Relay 	Used to 'hold off' transfer back to the mains after a mains failure and keep the generator on load. Transfer back to the mains supply is held off in <i>Auto mode</i> while the input is present. Typically, a key switch provides this input with <i>spring return to closed</i> functionality.
Oil Pressure Switch	A digital normally open or closed oil pressure switch gives this input. It allows low oil pressure protection.
Remote Start Off Load	If this input is active, operation is similar to the 'Remote Start on load' function except that the generator is not instructed to take the load. This function is used where an engine only run is required e.g. for exercise.
Remote Start On Load	When in auto mode, the module performs the start sequence and transfer load to the generator. In Manual mode, the load is transferred to the generator if the engine is already running, however in manual mode, this input does not generate start/stop requests of the engine.
Reset Maintenance Alarm 1	Provides an external digital input to reset the maintenance alarm 1
Reset Maintenance Alarm 2	Provides an external digital input to reset the maintenance alarm 2
Reset Maintenance Alarm 3	Provides an external digital input to reset the maintenance alarm 3
Simulate Auto Button	<p>NOTE: If a call to start is present when AUTO MODE is entered, the starting sequence begins. Call to Start comes from a number of sources depending upon module type and configuration and includes (but is not limited to) : Remote start input present, Mains failure, Scheduled run, Auxiliary mains failure input present, Telemetry start signal from remote locations.</p> <p>This input mimics the operation of the 'Auto' button and is used to provide a remotely located Auto mode push button.</p>

Function	Description
Simulate Lamp Test	This input is used to provide a test facility for the front panel indicators fitted to the module. When the input is activated all LED's illuminate. The input also serves a second function, in that it also provides a mute signal to silence the audible alarm. The input is recognised by the module as though it was the Push button on the module itself being operated.
Simulate Mains Available 	This function is provided to override the module's internal monitoring function. If this input is active, the module does not respond to the state of the incoming AC mains supply.
Simulate Manual Button	This input mimics the operation of the 'Manual' button and is used to provide a remotely located Manual mode push button.
Simulate Start Button	This input mimics the operation of the 'Start' button and is used to provide a remotely located start push button.
Simulate Stop Button	This input mimics the operation of the 'Stop' button and is used to provide a remotely located stop/reset push button.
Simulate Test on load button	This input mimics the operation of the 'Test' button and is used to provide a remotely located Test on load mode push button.
Smoke Limiting IEEE 37.2 – 18 Accelerating or Decelerating Device	This input instructs the module to give a <i>run at idle speed</i> command to the engine either via an output configured to <i>smoke limit</i> or by data commands when used with supported electronic engines.
Stop and Panel Lock	Combined function input that instructs the module to enter STOP mode and also perform the <i>Panel Lock</i> function. Once the input is active, the module does not respond to operation of the mode select or start buttons. The operator is still able to view the various instrumentation pages etc. (<i>Front panel configuration access is still possible while the system lock is active</i>).
Transfer To Generator/Open Mains IEEE 37.2 - 52 AC Circuit Breaker 	This input is used to transfer the load to the generator when running in MANUAL MODE
Transfer To Mains/ Open Generator IEEE 37.2-52 AC Circuit Breaker 	This input is used to transfer the load to the mains supply when running in MANUAL MODE

2.5 DIGITAL OUTPUTS

The screenshot shows the 'Digital Outputs' configuration window, divided into two sections: 'Relay Outputs (Supplied From Emergency Stop Input)' and 'Relay Outputs (DC Supply Out)'. Each section has a list of outputs (A-F) with dropdown menus for 'Source' and 'Polarity'. Callouts provide the following information:

- Top Callout:** 'These are greyed out as they are fixed and not adjustable.' (pointing to Output A and B in the Emergency Stop section).
- Left Callout:** 'Select what the output is to control' (pointing to the Source dropdown for Output C).
- Right Callout:** 'Select if the relay is to energise or de-energise upon activation of the source' (pointing to the Polarity dropdown for Output C).
- Bottom Callout:** 'These labels match the typical wiring diagram' (pointing to the Source labels like 'Close Gen Output').

2.5.1 OUTPUT SOURCES




The list of output sources available for configuration of the module relay.

Under the scope of IEEE 37.2, *function numbers* is also used to represent functions in microprocessor devices and software programs. Where the DSE output functions is represented by IEEE 37.2, the function number is listed below.





The outputs are in alphabetical order with the *parameter* first. For instance for over frequency output, it's listed as *Generator Overfrequency*.


 = Only available on DSE6120 MKII AMF Modules

Output Source	Activates...	Is Not Active....
Not Used	The output does not change state (Unused)	
Air Flap Relay	Normally used to control an air flap, this output becomes active upon an Emergency Stop or Over-speed situation.	Inactive when the set has come to rest
Alarm Mute	This input is used to silence the audible alarm from an external source such as a remote mute switch.	
Alarm Reset	This input is used to reset any latched alarms from a remote location. It is also used to clear any latched warnings which may have occurred (if configured) without having to stop the engine.	
Alternative Config Selected	Active when the alternative configuration is selected.	
Analogue Input A, B, C & D (Digital)	Active when the relevant analogue input, configured as digital input, is active	
Arm Safety On Alarms	Becomes active at the end of the <i>safety delay</i> timer whereupon all alarms configured to 'From Safety On' become active	Inactive when : <ul style="list-style-type: none"> • When the set is at rest • In the starting sequence before the Safety Delay timer has expired

Output Source	Activates...	Is Not Active....
Audible Alarm IEEE 37.2 – 74 alarm relay	Use this output to activate an external sounder or external alarm indicator. Operation of the Mute pushbutton resets this output once activated.	Inactive if no alarm condition is active or if the Mute pushbutton was pressed.
Auto Start Inhibit	Active when the <i>Auto-Start Inhibit</i> function is active.	
Battery High Voltage IEEE 37.2 – 59 DC Overvoltage Relay	This output indicates that a Battery Over voltage alarm has occurred.	Inactive when battery voltage is not High
Battery Low Voltage IEEE 37.2 – 27 DC Undervoltage Relay	This output indicates that a Battery Under Voltage alarm has occurred.	Inactive when battery voltage is not Low
CAN ECU Power	Used to switch an external relay to power the CAN ECU. Exact timing of this output is dependent upon the type of the engine ECU	
CAN ECU Stop	Active when the DSE controller is requesting that the CAN ECU stops the engine.	
Charge Alternator Shutdown	Active when the charge alternator shutdown alarm is active	
Close Gen Output IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the module selects the generator to be on load this control source is activated.	Inactive whenever the generator is not required to be on load
Close Gen Output Pulse IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the module selects the generator to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Close Mains Output IEEE 37.2 – 52 ac circuit breaker 	Used to control the load switching device. Whenever the module selects the mains to be on load this control source is activated.	The output is inactive whenever the mains is not required to be on load
Close Mains Output Pulse IEEE 37.2 – 52 ac circuit breaker 	Used to control the load switching device. Whenever the module selects the mains to be on load this control source is activated for the duration of the Breaker Close Pulse timer, after which it becomes inactive again.	
Combined Mains Failure 	Active when the mains supply is out of limits OR the input for Auxiliary Mains Failure is active	
Combined Maintenance Alarm	Active when any of the maintenance alarm is active.	
Combined Under and Over Frequency Alarm	Active when an <i>Under-Frequency</i> or <i>Over-Frequency Shutdown</i> alarm is active	
Combined Under and Over Frequency Warning	Active when an <i>Under-Frequency</i> or <i>Over-Frequency Warning</i> alarm is active	
Combined Under and Over Voltage Alarm	Active when an <i>Under-Voltage</i> or <i>Over-Voltage Shutdown</i> alarm is active	
Combined Under and Over Voltage Warning	Active when an <i>Under-Voltage</i> or <i>Over-Voltage Warning</i> alarm is active	
Common Alarm	Active when one or more alarms (of any type) are active	The output is inactive when no alarms are present
Common Electrical Trip	Active when one or more <i>Electrical Trip</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Shutdown	Active when one or more <i>Shutdown</i> alarms are active	The output is inactive when no shutdown alarms are present
Common Warning	Active when one or more <i>Warning</i> alarms are active	The output is inactive when no warning alarms are present
Cooling Down	Active when the Cooling timer is in progress	The output is inactive at all other times
DEF Level Low	Active when <i>DEF Level Low</i> CAN alarm is active.	
DEF Level Low Alarm	Active when <i>DEF Level Low Alarm</i> is active.	
Digital Input A, B, C, D, E & F	Active when the relevant digital input is active	
Display Heater Fitted and On	Active when the display heater is on	


Output Source	Activates...	Is Not Active...
DPF Forced Regeneration Interlock Active	Active when the <i>DPF Force Regeneration Interlock</i> is active	
DPF Forced Regeneration Requested	Active when the <i>DPF Force Regeneration</i> is active	
DPF Non Mission State	Active when the <i>DPF Non-Mission State</i> is active	
DPF Regeneration In Progress	Active when the <i>DPF Regeneration</i> is in progress	
DPTC Filter	Active when the diesel particulate filter CAN alarm is active	
ECU (ECM) Data Fail	Active when the ECU (ECM) Data Fail is active.	Inactive when the ECU (ECM) Data Fail is inactive.
ECU (ECM) Shutdown	The engine ECU (ECM) has indicated that a Shutdown alarm is present.	Inactive when no Shutdown alarm from the ECU (ECM) is not present
ECU (ECM) Warning	The engine ECU (ECM) has indicated that a Warning alarm is present.	Inactive when no Warning alarm from the ECU (ECM) is not present
Emergency Stop IEEE 37.2 – 5 Stopping Device	Active when the <i>Emergency Stop</i> input has been activated	
Energise To Stop	Normally used to control an <i>Energise to Stop</i> solenoid, this output becomes active when the controller wants the set to stop running.	Becomes inactive a configurable amount of time after the set has stopped. This is the <i>ETS hold time</i> .
Fail to Close Generator	Active when the <i>Generator Closed Auxiliary</i> input fails to become active after the <i>Close Generator Output</i> or <i>Close Generator Output Pulse</i> becomes active	
Fail to Close Mains	Active when the <i>Mains Closed Auxiliary</i> input fails to become active after the <i>Close Mains Output</i> or <i>Close Mains Output Pulse</i> becomes active	
Fail To Start IEEE 37.2 - 48 Incomplete Sequence Relay	Becomes active if the set is not seen to be running after the configurable number of start attempts	
Fail To Stop IEEE 37.2 - 48 Incomplete Sequence Relay	If the set is still running a configurable amount of time after it has been given the stop command, the output becomes active. This configurable amount of time is the <i>Fail to Stop Timer</i> .	
Fan Control	Energises when the engine becomes available (up to speed and volts). This output is designed to control an external cooling fan. When the engine stops, the cooling fan remains running for the duration of the Fan Overrun Delay.	
Flexible Sensor A, B, C or D Low/High – Alarm/Pre- Alarm	Active when the relevant flexible sensor alarm is active	
Fuel Level High/Low – Alarm/Pre-Alarm	Active when the relevant <i>Fuel Level High/Low Alarm/Pre-Alarm</i> is active.	
Fuel Pump Control IEEE 37.2 – 71 Level Switch	Becomes active when the <i>Fuel level</i> falls below the <i>Fuel Pump Control ON</i> setting and is normally used to transfer fuel from the bulk tank to the day tank.	If the output is already active it becomes inactive when the <i>Fuel level</i> is above the <i>Fuel Pump Control OFF</i> settings.
Fuel Relay	Becomes active when the controller requires the governor/fuel system to be active.	Becomes inactive whenever the set is to be stopped, including between crank attempts, upon controlled stops and upon fault shutdowns.
Gas Choke On	Becomes active during starting for the duration of the Gas Choke timer. Normally used to choke a gas engine.	Inactive at all other times
Gas Ignition	Becomes active during starting.	Becomes inactive a configurable amount of time after the <i>Fuel Relay</i> becomes inactive. This is the <i>Gas Ignition Off</i> timer.
Generator Loading Frequency Not Reached	Indicates that the generator frequency has not reached the configured <i>Loading Frequency</i> during the starting process.	
Generator Loading Voltage Not Reached	Indicates that the generator voltage has not reached the configured <i>Loading Voltage</i> during the starting process.	
Gen Over Frequency Overshoot Alarm	Becomes active when the over frequency overshoot alarm is active	

Output Source	Activates...	Is Not Active...
Generator Available	Becomes active when the generator is available to take load.	Inactive when <ul style="list-style-type: none"> Loading voltage and loading frequency have not been reached After electrical trip alarm During the starting sequence before the end of the warming timer.
Generator High Volts Shutdown	Active when the generator voltage exceeds the shutdown level.	
Generator Over Frequency Shutdown	Becomes active when the over frequency shutdown alarm is active	
HEST	Active when the High Exhaust System Temperature CAN alarm is active	
KW Overload Alarm	Active when the measured kW are above the setting of the kW overload alarm. Used to give alarms on overload, control a dummy load switch or for load shedding functionality.	
Lamp Test	Active when the lamp test is activated by a digital input or by pressing the Mute/Lamp Test control button	
Loading Frequency Not Reached	Active when the generator frequency has not reached the configured Loading Frequency during the starting process.	
Loading Voltage Not Reached	Active when the generator voltage has not reached the configured Loading Voltage during the starting process.	
Louvre Control	Active when the fuel relay becomes active. Normally used to drive ventilation louvres for the generator set.	
Low Fuel Level	Active when the Low Fuel Level alarm becomes active.	
Low Load	Active when the measured kW are below the setting of the Low Load alarm. Used to give alarms on low loads, or to control a dummy load switch.	
Main Config Selected	Active when the main configuration is active.	
Mains Failure IEEE 37.2 - 81 Frequency Relay IEEE 37.2 – 27AC Undervoltage Relay IEEE 37.2 – 59AC Overvoltage Relay 	The output indicates that one or more of the module's sources of determining mains failure is active.	
Mains Phase Rotation Alarm 	Active when the detected mains phase sequence is different than the configured Mains Phase Rotation	
Maintenance Alarm 1, 2 or 3 Due	Active when the relevant maintenance alarm is due.	
Manual Restore Contact	Active when the manual restore contact input is active	
MPU open circuit	This output indicates that the module has detected an open circuit failure in the Magnetic Pickup transducer circuit.	
Open Gen Output IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the module selects the generator to be off load this control source is activated.	Inactive whenever the generator is required to be on load
Open Gen Output Pulse IEEE 37.2 – 52 ac circuit breaker	Used to control the load switching device. Whenever the module selects the generator to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	
Open Mains Output IEEE 37.2 – 52 ac circuit breaker 	Used to control the load switching device. Whenever the module selects the mains to be off load this control source is activated.	The output is inactive whenever the mains is required to be on load
Open Mains Output Pulse IEEE 37.2 – 52 ac circuit breaker 	Used to control the load switching device. Whenever the module selects the mains to be off load this control source is activated for the duration of the Breaker Open Pulse timer, after which it becomes inactive again.	


Output Source	Activates...	Is Not Active....
Overspeed Delayed Alarm IEEE 37.2 – 12 Over Speed Device	Active when the <i>Over Speed Delayed</i> alarm is active	
Over Speed Shutdown IEEE 37.2 – 12 over speed device	Active if the engine speed exceeds the Over Speed Shutdown setting	
Over Speed Overshoot Alarm	Active if the engine speed exceeds the Over Speed Overshoot alarm setting	
Preheat During Preheat Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> The set is stopped The preheat timer has expired
Preheat Until End Of Cranking	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> The set is stopped The set has reached <i>crank disconnect</i> conditions
Preheat Until End Of Safety Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> The set is stopped The set has reached the end of the <i>safety delay</i> timer
Preheat Until End of Warming Timer	Becomes active when the preheat timer begins. Normally used to control the engine preheat glow-plugs.	Inactive when : <ul style="list-style-type: none"> The set is stopped The set has reached the end of the <i>warming</i> timer
Remote Start OnLoad	Active when the <i>Remote Start on Load</i> input is active	
Reset Maintenance 1, 2 or 3	Active when the relevant <i>Maintenance Alarm Reset</i> is active	
Scheduled Auto Start Inhibit	Active when the <i>Inhibit Scheduled Run</i> input is active	
SCR Inducement	Active when <i>SCR Inducement CAN Alarm</i> is active	
Smoke Limiting	Becomes active when the controller requests that the engine runs at idle speed. As an output, this is used to give a signal to the <i>Idle input</i> of an engine speed governor (if available)	Becomes inactive when the controller requests that the engine runs at rated speed.
Start Relay IEEE 37.2 – 54 Turning Gear Engaging Device	Active when the controller requires the cranking of the engine.	
System in Auto Mode	Active when Auto mode is selected	
System in Manual Mode	Active when Manual mode is selected	
System in Stop Mode	Active when Stop mode is selected	
System in Test Mode	Active when Test On Load mode is selected	
Waiting For Manual Restore 	Becomes active when the generator is on load and the mains supply is healthy but an input configured to Manual Restore is active. This is used to signal to an operator that action is required before the set transfers back to the mains supply.	

2.6 TIMERS


Many timers are associated with alarms. Where this occurs, the timer for the alarm is located on the same page as the alarm setting. Timers not associated with an alarm are located on the timers page. The *timers* page is subdivided into smaller sections. Select the required section with the mouse.




2.6.1 START TIMERS



= Only available on DSE6120 MKII AMF Modules

Timer	Description
 Mains Transient Delay	Used to give a delay between sensing mains failure and acting upon it. This is used to prevent dropouts of the mains breaker and operation of the system due to mains supply transient conditions.
Start Delay	The amount of time delay before starting in AUTO mode. This timer is activated upon the respective start command being issued. Typically this timer is applied to prevent starting upon fleeting start signals.
Delay Crank	The amount of time delay between the fuel relay and the crank relay energising. This is typically used to allow fuel systems to prime.
Cranking	The amount of time for each crank attempt
Cranking Rest	The amount of time between multiple crank attempts.
Smoke Limit	The amount of time that the engine is requested to run at idle speed upon starting. This is typically used to limit emissions at startup.
Smoke Limit Off	The amount of time that the engine takes to run up to rated speed after removal of the command to run at idle speed. If this time is too short, an <i>Underspeed</i> alarm is detected. If the time is too long, <i>Underspeed</i> protection is disabled until the <i>Smoke Limit Time Off</i> time has expired.
Safety On Delay	The amount of time at startup that the controller ignores oil pressure and engine speed and other delayed alarms. This is used to allow the engine to run up to speed before protections are activated.
Warming	The amount of time the engine runs before being allowed to take load. This is used to warm the engine to prevent excessive wear.
ECU Override	The amount of time the CAN ECU Power stays energised when the Start button is pressed in Stop mode.

2.6.2 LOAD / STOPPING TIMERS



Load/Stopping Timers

Load Timers

Transfer Time	0.7s
Breaker Close Pulse	0.5s
Breaker Trip Pulse	0.5s


Stopping Timers

Return Delay	30s
Cooling	1m
Cooling at Idle	0s
ETS Solenoid Hold	0s
Fail to Stop Delay	30s


Click and drag to change the setting.
Timers increment in steps of 1second up to one minute, then in steps of 30seconds up to 30minutes, then in steps of 30minutes thereafter (where allowed by the limits of the timer).



= Only available on DSE6120 MKII AMF Modules

Timer	Description
 Transfer Time	The time between one load switch opening and the other closing. Used during transfer to and from the generator.
Breaker Close Pulse	The amount of time that <i>Breaker Close Pulse</i> signal is present when the request to close a breaker is given.
Breaker Trip Pulse	The amount of time that <i>Breaker Open Pulse</i> signal is present when the request to open a breaker is given.
Return Delay	A delay, used in auto mode only, that allows for short term removal of the request to stop the set before action is taken. This is usually used to ensure the set remains on load before accepting that the start request has been removed.
Cooling	The amount of time that the set is made to run OFF LOAD before being stopped. This is to allow the set to cool down and is particularly important for engines with turbo chargers.
Cooling At Idle	The amount of time that the set is made to run OFF LOAD at <i>Idle Speed</i> before being stopped.
ETS Solenoid Hold	The amount of time the <i>Energise to stop</i> solenoid is kept energised after the engine has come to rest. This is used to ensure the set has fully stopped before removal of the stop solenoid control signal.
Fail To Stop Delay	If the set is called to stop and is still running after the <i>fail to stop</i> delay, a <i>Fail to Stop</i> alarm is generated.


2.6.3 MODULE TIMERS




Timer	Description
Page	If the module is left unattended for the duration of the Page Timer it reverts to show the Status page.
Scroll	The scroll time between parameters on a selected page.
Audible Alarm Duration	When an alarm is active on the module, this is the time duration during which the <i>Audible Alarm</i> digital output is active. This is configurable when the <i>Limit Audible Alarm Duration</i> option is enabled under <i>Module Options</i> .

2.7 GENERATOR

The *Generator* section is subdivided into smaller sections. Select the required section with the mouse.



2.7.1 GENERATOR OPTIONS



Parameter	Description
Alternator Fitted	<input type="checkbox"/> = There is no alternator in the system, it is an <i>engine only</i> application <input checked="" type="checkbox"/> = An alternator is fitted to the engine, it is a <i>generator</i> application.
AC System	Allows a number of AC systems to be catered for. Selecting the AC system shows the connections required for that particular system, along with the relevant connection numbers on the controller.

2.7.2 GENERATOR VOLTAGE

Generator Voltage Alarms

Under Voltage Alarms

Shutdown
 Trip 318 V PhPh 80.0 % 318V PhPh
 Activation Delay 0.0s

Pre-alarm
 Trip 339 V PhPh 85.2 % 339V PhPh

Loading Voltage 358 V PhPh 90.0 % 358V PhPh

Nominal Voltage 398 V PhPh 100.00 % 398V PhPh

Over Voltage Alarms

Pre-alarm
 Return 439 V PhPh 110.4 %
 Trip 458 V PhPh 115.2 %

Shutdown
 Trip 479 V PhPh 120.4 % 479V PhPh
 Activation Delay 0.0s

2.7.2.1 UNDER VOLTAGE ALARMS

Alarm	Description
Generator Under Voltage Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give a Shutdown alarm <input checked="" type="checkbox"/> = Generator Under Volts gives a shutdown alarm in the event of the generator output falling below the configured <i>Under Volts Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Undervolts Alarm Trip</i> value is adjustable to suit user requirements.
Generator Under Voltage Pre-Alarm IEEE 37.2 - 27AC Undervoltage Relay	<input type="checkbox"/> = Generator Under Volts does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Volts gives a warning alarm in the event of the generator output falling below the configured <i>Under Volts Pre-Alarm Trip</i> value. The <i>Warning</i> is automatically reset when the generator output voltage rises above the configured <i>Loading Voltage</i> level.
Loading Voltage	This is the minimum voltage the generator must be operating at before the module considers it available to take the load. It is also the voltage above the under voltage trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With an undervolts trip of 184.0V and an undervolts return of 207.0V, the output voltage must return to 207.0V following an under voltage event to be considered within limits.)

2.7.2.2 NOMINAL VOLTAGE

Nominal Voltage	This is used to calculate the percentages of the alarm setpoints.
-----------------	---

2.7.2.3 OVER VOLTAGE ALARM

<p>Generator Over Voltage Pre-Alarm IEEE 37.2 – 59 AC Overvoltage Relay</p>	<p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Volts gives a <i>Warning</i> alarm in the event of the generator output voltage rising above the configured <i>Over Volts Pre-Alarm Trip</i> value. The <i>Warning</i> is automatically reset when the generator output voltage falls below the configured <i>Return</i> level. The <i>Over Volts Pre-Alarm Trip</i> value is adjustable to suit user requirements.</p>
<p>Generator Over voltage IEEE 37.2 – 59 AC Overvoltage Relay</p>	<p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Volts gives a <i>Shutdown</i> alarm in the event of the generator output rising above the configured <i>Over Volts Alarm Trip</i> value for longer than the <i>Activation Delay</i>. The <i>Overvolts Alarm Trip</i> value is adjustable to suit user requirements.</p>

2.7.3 GENERATOR FREQUENCY


2.7.3.1 UNDER FREQUENCY ALARMS

Alarm	IEEE designation
Generator Under Frequency IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give a Shutdown alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives a Shutdown alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Shutdown Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Underfrequency Alarm Trip</i> value is adjustable to suit user requirements.
Generator Under Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay	<input type="checkbox"/> = Generator Under Frequency does NOT give a warning alarm <input checked="" type="checkbox"/> = Generator Under Frequency gives a warning alarm in the event of the generator output frequency falling below the configured <i>Under Frequency Pre-Alarm Trip</i> value. The <i>Warning</i> is automatically reset when the generator output frequency rises above the configured <i>Loading Frequency</i> level. The <i>Under Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Loading Frequency	This is the minimum frequency the generator must be operating at before the module considers it available to take the load. It is also the frequency above the under frequency trip that the generator output must return to before the module considers that the supply is back within limits. (i.e. With a under frequency trip of 45.0Hz and a under frequency return of 48.0Hz, the mains frequency must return to 48.0Hz following an under frequency event to be considered within limits.)

2.7.3.2 NOMINAL FREQUENCY

Nominal Frequency	This setting is used to configure the generator nominal frequency. This is also used to calculate the percentages of the alarm setpoints.
-------------------	---

2.7.3.3 OVER FREQUENCY ALARMS

<p>Generator Over Frequency Pre-Alarm IEEE 37.2 -81 Frequency Relay</p>	<p><input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Generator Over Frequency gives a warning alarm in the event of the generator output frequency rising above the configured <i>Over frequency Pre-Alarm Trip</i> value. The <i>Warning</i> is automatically reset when the generator output frequency falls below the configured <i>Return</i> level. The <i>Over Frequency Pre-Alarm Trip</i> value is adjustable to suit user requirements.</p>
<p>Generator Over Frequency IEEE 37.2 -81 Frequency Relay</p>	<div style="border: 1px solid black; padding: 5px;"> <p> NOTE: When the frequency is selected as the only source of speed sensing (i.e. no Mag-pickup fitted), then the generator over frequency alarm trip is not disabled as it provides an overspeed protection function. If a Mag-pickup is fitted and selected as the speed sensing source it is possible to disable the over frequency trip if required.</p> </div> <p><input type="checkbox"/> = Generator Over Frequency does NOT give a Shutdown alarm <input checked="" type="checkbox"/> = Generator Over Frequency gives a shutdown alarm in the event of the generator output rising above the displayed <i>Over Frequency Trip</i> value for longer than the <i>Activation Delay</i>. The <i>Over Frequency Trip</i> value is adjustable to suit user requirements.</p>
<p>Overshoot Delay</p>	<p>To prevent spurious over-frequency alarms at start up, the module includes configurable <i>Over Frequency Overshoot</i> protection. This allows the frequency to 'overshoot' the <i>Over-Frequency Shutdown</i> level during the starting process for a short time.</p> <p>Rather than 'inhibiting' the <i>Over Frequency</i> alarms, the levels are temporarily raised by the DSE module's default <i>Over Frequency Overshoot %</i> for the duration of the <i>Overshoot Delay</i> from starting.</p>

2.7.4 GENERATOR CURRENT

The screenshot shows the 'Generator Current' configuration window, divided into several sections:

- Generator Current Options:**
 - CT Primary (L1,L2,L3,N): 600 A
 - CT Location: Gen
 - Full Load Rating: 500 A
- Overcurrent Alarm:**
 - Immediate Warning:
 - IDMT Alarm:
 - Trip: 100 % (slider to 500 A)
 - Time Multiplier: 36
 - Action: Electrical Trip
- Generator Rating:**
 - kW Rating: 200 kW (slider)
- Overload Protection:**
 - Enable:
 - Action: Shutdown
 - Trip: 100 % (slider to 200 kW)
 - Return: 99 % (slider to 198 kW)
 - Delay: 5s (slider)

Callouts provide additional context:

- Callout 1: 'This is the CT primary value as fitted to the set (CT secondary must be 5A) The full load rating is the 100% rating of the set in Amps.'
- Callout 2: 'Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled.'
- Callout 3: 'Type the value or click the up and down arrows to change the settings'

2.7.4.1 GENERATOR CURRENT OPTIONS

Parameter	Description
CT Primary	Primary rating of the Current Transformers
CT Secondary	Secondary rating of the Current Transformers
CT Location	<p>Gen: The CTs are in the feed from the generator, the module shows only generator load</p> <p>Load: The CTs are in the feed to the load, the module then displays load current, provided by the mains supply or the generator.</p>

2.7.4.2 OVERCURRENT ALARM

The overcurrent alarm combines a simple warning trip level combined with a fully functioning IDMT curve for thermal protection.

Immediate warning

IEEE 37.2 -50 instantaneous overcurrent relay

If the current exceeds the *Trip* level the *Immediate Warning* activates.

IDMT Alarm

IEEE 37.2 -51 AC time overcurrent relay (shutdown / electrical trip)

If the *IDMT Alarm* is enabled, the 72/7300 Series controller begins following the IDMT 'curve'. If the *Trip* is surpassed for an excess amount of time the *IDMT Alarm* triggers (*Shutdown* or *Electric trip* as selected in *Action*).

The higher the overload, the faster the trip. The speed of the trip is dependent upon the fixed formula :

$$T = t / ((I_A / I_T) - 1)^2$$


Where: T is the tripping time in seconds

I_A is the actual current of the most highly loaded line (L1 or L2 or L3)

I_T is the delayed over-current trip point

t is the time multiplier setting and also represents the tripping time in seconds at twice full load (when $I_A / I_T = 2$).

Typical settings for the *IDMT Alarm* when used on a brushless alternator are :



These settings provide for normal running of the generator up to 100% full load. If full load is surpassed, the *Immediate Warning* alarm is triggered, the set continues to run.


The effect of an overload on the generator is that the alternator windings begin to overheat, the aim of the *IDMT alarm* is to prevent the windings being overload (heated) too much. The amount of time that the set is safely overloaded is governed by how high the overload condition is.

See overleaf for details of the IDMT alarm factory settings and examples of different settings for the *Time Multiplier* (t).

The IDMT alarm factory settings, allows for overload of the set to the limits of the *Typical Brushless Alternator* whereby 110% overload is permitted for 1 hour.

If the set load is reduced, the controller then *follows* a cooling curve. This means that a second overload condition may trip much sooner than the first as the controller *knows* if the windings have not cooled sufficiently.

For further details on the *Thermal damage curve* of your alternator, you are referred to your alternator manufacturer.



Creating an Excel spreadsheet of the IDMT curve.

The formula used: $T = t / ((I_A / I_T) - 1)^2$

Is simplified for addition into a spreadsheet. This is useful for 'trying out' differering values of *t* (*Time Multiplier*) and viewing the results, without actually testing this on the engine.

	A	B	C	D	E	F	G
1		1.01	1.02	1.03	1.04	1.05	1.06
2	36	360000	90000	40000	22500	14400	10000

t – Time Multiplier
Factory setting is 36

T – Tripping time (seconds)

(I_A / I_T)
Multiple of the *Trip* setting
(from 1.01 to 3.0 in steps of 0.1)

The formula for the *Tripping Time* cells is : `=A2/POWER((B$1-1),2)`

2.7.4.3 GENERATOR RATING

Parameter	Description
Generator KW Rating	The generator kW rating must be set in order for the <i>Generator Power</i> functions to be correctly utilised.

2.7.4.4 OVERLOAD PROTECTION

Parameter	Description
Overload Protection	<input type="checkbox"/> = Overload Protection function is disabled. <input checked="" type="checkbox"/> = <i>kW Overload Alarm</i> activated when the kW level exceeds the <i>Trip</i> level for the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Electrical Trip Indication Shutdown Warning
Trip	Set the percentage of total kW load at which the <i>Overload Alarm</i> is activated
Return	When the <i>Action</i> configured to <i>Warning</i> , the <i>Warning</i> is automatically reset when the generator kW level falls below the configured <i>Return</i> level.
Delay	The amount of time before the module activates the <i>Overload Alarm</i> .

2.7.5 LOW LOAD


NOTE: Often alternators are specified to run not less than a certain kW level. The *Low Load Alarm* provides protection for the alternators running at low loads below their specified levels.

Parameter	Description
Low Load Alarm	<input type="checkbox"/> = Low Load Protection function is disabled. <input checked="" type="checkbox"/> = <i>Low Load Alarm</i> activated when the kW level falls the <i>Trip</i> level for the configured <i>Delay</i> time.
Description	Provide a text to display when alarm is active.
Action	Select the type of alarm required from the list: Electrical Trip Indication Shutdown Warning
Trip	Set the percentage of kW load level at which the <i>Low Load Alarm</i> is activated
Return	When the <i>Action</i> configured to <i>Warning</i> , the <i>Warning</i> is automatically reset when the generator kW level rises above the configured <i>Return</i> level.
Delay	The amount of time before the module activates the <i>Low Load Alarm</i> .




2.7.6 MAINS

 = Only available on DSE6120 MKII AMF Modules





The *Mains* section is subdivided into smaller sections. Select the required section with the mouse.



2.7.7 MAINS OPTIONS


Timer	Description
 Mains Failure Detection	<input type="checkbox"/> = The module ignores the status of the mains supply. <input checked="" type="checkbox"/> = The module monitors the mains supply and use this status for automatically starting and stopping the set in auto mode.
 Immediate Mains Dropout	<input type="checkbox"/> = Upon mains failure, the mains load switch is kept closed until the generator is up to speed and volts. <input checked="" type="checkbox"/> = Upon mains failure, the mains load switch is opened immediately, subject to the setting of the <i>mains transient</i> timer.
 AC System	These settings are used to detail the type of AC system to which the module is connected: 3 phase 4 wire, 1 phase 2 wire, 2 phase 3 wire – L1-L2, 2 phase 3 wire – L1-L3, 3 phase 3 wire, 3 phase 4 wire delta This list is not exhaustive. DSE reserve the right to add to this list as part of our policy of continual development

2.7.8 MAINS ALARMS

Alarm	IEEE designation
Mains Under Voltage IEEE 37.2 – 27 AC Undervoltage Relay 	<input type="checkbox"/> = Mains Under Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Under Voltage gives an alarm in the event of the mains voltage falling below the configured <i>Under Voltage Trip</i> value. The <i>Under Voltage Trip</i> value is adjustable to suit the application. The alarm is reset and the mains is considered within limits when the mains voltage rises above the configured <i>Under Voltage Return</i> level.
Mains Over Voltage IEEE 37.2 – 59 AC Overvoltage Relay 	<input type="checkbox"/> = Mains Over Voltage detection is disabled <input checked="" type="checkbox"/> = Mains Over Voltage gives an alarm in the event of the mains voltage rising above the configured <i>Over Voltage Trip</i> value. The <i>Over Voltage Trip</i> value is adjustable to suit the application. The alarm is reset and the mains is considered within limits when the mains voltage falls below the configured <i>Over Voltage Return</i> level.
Mains Under Frequency IEEE 37.2 – 81 Frequency Relay 	<input type="checkbox"/> = Mains Under Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Under Frequency gives an alarm in the event of the mains frequency falling below the configured <i>Under Frequency Trip</i> value. The <i>Under Frequency Trip</i> value is adjustable to suit the application. The alarm is reset and the mains is considered within limits when the mains frequency rises above the configured <i>Under Frequency Return</i> level.
Mains Over Frequency IEEE 37.2 – 81 Frequency Relay 	<input type="checkbox"/> = Mains Over Frequency detection is disabled <input checked="" type="checkbox"/> = Mains Over Frequency gives an alarm in the event of the mains frequency rising above the configured <i>Over Frequency Trip</i> value. The <i>Over Frequency Trip</i> value is adjustable to suit the application. The alarm is reset and the mains is considered within limits when the mains frequency falls below the configured <i>Over Frequency Return</i> level.

2.8 ENGINE


The *Engine* section is subdivided into smaller sections. Select the required section with the mouse.



2.8.1 OIL PRESSURE

If a CAN Engine File is selected – Most engines give oil pressure from CAN link. In these cases, Analogue Input A is configured as Flexible Analogue or Digital Input. Configuration of Flexible Analogue Inputs and Digital Inputs is detailed elsewhere in this document.

Where the CAN engine does not support oil pressure over CAN link, Analogue input A is selectable as either digital input, analogue flexible input, or as analogue oil pressure sensor.



Parameters described overleaf...

Parameter	Description
Measured Quantity	Select the sensor signal: Current: for sensors with maximum range of 0 mA to 20 mA Resistive: for sensors with maximum range of 0 Ω to 480 Ω Voltage: for sensors with maximum range of 0 V to 10 V
Input Type	Select the sensor curve from a pre-defined list or create a user-defined curve.
Enable Open Circuit Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Open Circuit Alarm</i> is active when the module detects an open circuit when the sensor is disconnected
Low Oil Pressure Shutdown	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Oil Pressure Shutdown Alarm</i> is active when the measured oil pressure drops below the configured <i>Trip</i> level.

2.8.2 COOLANT TEMPERATURE

If a **CAN Engine File** is selected – Engines give temperature measurements from CAN link. Analogue Input B is configured as Digital Input. Configuration is the same as for Digital Inputs, detailed elsewhere in this document.

The screenshot shows the 'Coolant Temperature' configuration window. It includes a 'Temperature Sensor' section with an 'Input Type' dropdown set to 'VDO 120 °C' and an 'Edit...' button. Below this is the 'High Coolant Temperature Alarms' section, which has three rows: 'Shutdown' with a 'Trip' value of 96 °C, 'Pre-alarm' with a checked checkbox and a 'Trip' value of 90 °C, and 'Return' with a 'Trip' value of 88 °C. A temperature gauge is visible on the right side of the interface.

Callouts provide the following information:

- Select the sensor type:** Points to the 'Input Type' dropdown menu.
- Click to edit the 'sensor curve'.** See section entitled *Editing the Sensor Curve*.: Points to the 'Edit...' button.
- Configurable only when a CAN engine file is selected or when the Analogue Input is configured as Coolant Temperature Sensors.**: Points to the 'High Coolant Temperature Alarms' section.

Parameter	Description
Input Type	Select the sensor curve from a pre-defined list or create a user-defined curve.
High Coolant Temperature Shutdown	The <i>High Coolant Temperature Shutdown Alarm</i> is active when the measured coolant temperature rises above the configured <i>Trip</i> level.
High Coolant Temperature Pre-Alarm	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Coolant Temperature Warning Alarm</i> is active when the measured coolant temperature rises above the configured <i>Trip</i> level. The <i>Warning</i> is automatically reset when the coolant temperature falls below the configured <i>Return</i> level.

2.8.3 FUEL LEVEL

Fuel Level

Configurable only when the *Analogue Input* is configured as *Fuel Level Sensors*.

Input Type: VDO Ohm range (10-18) [Edit...](#)

Click to edit the 'sensor curve'. See section entitled *Editing the Sensor Curve*.

Sensor Alarms

Low Alarm Enable Action: Shutdown

Low Alarm: 10% Delay: 0s

Select the type of alarm required. For details of these, see the section entitled *Alarm Types* elsewhere in this document.

Low Pre-alarm Enable Low Pre-alarm Trip: 25% Low Pre-alarm Return: 30% Delay: 0s

High Pre-alarm Enable High Pre-alarm Return: 65% High Pre-alarm Trip: 70% Delay: 0s

Click to enable or disable the alarms. The relevant values below appears *greyed out* if the alarm is disabled.

High Alarm Enable Action: High Alarm: 90% Delay: 0s

Fuel Pump Control

Enable On: 25% Off: 75%

Tank

Tank Size: 0 Units: Litres

Hint : Set an output to "Fuel pump control". This is used to transfer fuel from a bulk tank to the day tank, for example.

Parameters are detailed overleaf...

Editing the Configuration

Parameter	Description
Input Type	Select the sensor curve from a pre-defined list or create a user-defined curve.
Low Alarm Enable	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Fuel Level Alarm</i> is active when the measured fuel level drops below the <i>Low Alarm</i> setting for the configured <i>Delay</i> time.
Low Pre-Alarm Enable	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>Low Fuel Level Pre-Alarm</i> is active when the measured fuel level drops below the <i>Low Pre-Alarm Trip</i> setting for the configured <i>Delay</i> time. The pre-alarm is automatically reset when the fuel level exceeds the configured <i>Low Pre-Alarm Return</i> setting.
High Pre-Alarm Enable	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Fuel Level Pre-Alarm</i> is active when the measured fuel level rises above the <i>High Pre-Alarm Trip</i> setting for the configured <i>Delay</i> time. The pre-alarm is automatically reset when the fuel level drops below the configured <i>High Pre-Alarm Return</i> setting.
High Alarm Enable	<input type="checkbox"/> = Alarm is disabled. <input checked="" type="checkbox"/> = The <i>High Fuel Level Alarm</i> is active when the measured fuel level rises above the <i>High Alarm</i> setting for the configured <i>Delay</i> time.
Fuel Pump Control	<input type="checkbox"/> = Fuel Pump Control is disabled. <input checked="" type="checkbox"/> = Allows the module to control an external fuel pump to transfer fuel from a bulk tank to the day tank. A digital output configured for <i>Fuel Pump Control</i> energises when the fuel level falls below the configured <i>On</i> setting and de-energises when the fuel level exceeds the configured <i>Off</i> setting.
Tank Size	Enter the size of the fuel tank where the fuel level sensor is fitted.
Units	Select the type of units to be used for the fuel level: Imperial Gallons Litres US Gallons

2.8.4 DEF LEVEL

NOTE: Configuration of alarms in this section only has effect when the ECU (ECM) supports DEF Level.

NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CANbus message; however, the ECU (ECM) still shuts down the engine depending on the alarm severity.

DEF Level is a CANbus message from the ECU (ECM). The following parameters allow configuration of how the DSE module responds to the DEF Level.

Parameter	Description
DEF Level Low Alarm	<input type="checkbox"/> = Disable the alarm <input checked="" type="checkbox"/> = <i>DEF Low Alarm</i> activates when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time.
Action	Select the type of alarm required from the list: Shutdown Electrical Trip For details of these, see the section entitled <i>Alarm Types</i> elsewhere in this document.
DEF Level Low Pre-Alarm	<input type="checkbox"/> = The Pre-alarm is disabled. <input checked="" type="checkbox"/> = <i>DEF Low Pre-Alarm</i> activates when the <i>DEF Level</i> sent from the ECU is below the configured <i>Trip</i> level for longer than the configured <i>Delay</i> time. The Pre-Alarm is deactivated when the <i>DEF Level</i> rises above the <i>Return</i> level.

2.8.5 ENGINE OPTIONS

Engine Options

ECU (ECM) Options

- Engine State: Conventional Diesel
- Enhanced J1939:
- Alternative Engine Speed:
- Modbus Engine Comms Port: RS485 Port
- Disable ECM Speed Control:

Miscellaneous Options

- J1939-75 Instrumentation Enable:
- J1939-75 Alarms Enable:
- CAN source address (instrumentation): 44

Startup Options

- Start Attempts: 3

Pre-heat

- Enabled:
- On: 50 °C (122 °F)
- Duration: 0s

Post-heat

- Enabled:
- On: 50 °C (122 °F)
- Duration: 0s

2.8.5.1 MISCELLANEOUS OPTIONS

NOTE: For a full list of the J1939-75 alarms and instrumentation, refer to DSE Publication: *057-253 DSE7300MKII Operator Manual* which is found on our website: www.deepseapl.com

Parameter	Description
J1939-75 Instrumentation Enable	Allows the DSE module to be interrogated by another CAN device and transfer the generator set instrumentation over J1939 link.
J1939-75 Alarms Enable	Allows the DSE module to be interrogated by another CAN device and transfer the alarms over J1939 link.
CAN Source Address (Instrumentation)	<p>NOTE: For a full list of the J1939-75 engine message and instrumentation, refer to DSE Publication: <i>057-253 DSE7300MKII Operator Manual</i> which is found on our website: www.deepseapl.com</p> <p>Set the <i>CAN Source Address</i> for the DSE module over which other CANbus devices read the generator set instrumentation.</p>

2.8.5.2 STARTUP OPTIONS

Parameter	Description
Start Attempts	<p>The number of starting attempts the module makes.</p> <p>If the module does not detect that the engine has fired before the end of the <i>Cranking Time</i>, then the current start attempt is cancelled and the <i>Crank Rest</i> time takes place before the next crank attempt begins.</p> <p>If, after all configured <i>start attempts</i>, the engine is not detected as running, the <i>Fail to Start</i> shutdown alarm is generated.</p> <p>The engine is detected as running by checking all methods of <i>Crank Disconnect</i>. For further details, see the section entitled <i>Crank Disconnect</i> elsewhere in this document.</p>

2.8.5.3 PRE-HEAT


 **NOTE:** For this feature to have effect, configure a digital output for *Pre-Heat*.

 **NOTE:** Depending on *Engine Type* configuration, this is controlled direct by the ECU (ECM).

Parameter	Description
Enabled	<p><input type="checkbox"/> = The <i>Pre-Heat</i> digital output is always active.</p> <p><input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time before cranking.</p>
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active before cranking

2.8.5.4 POST-HEAT

 **NOTE:** For this feature to have effect, configure a digital output for *Pre-Heat*.

 **NOTE:** Depending on *Engine Type* configuration, this is controlled direct by the ECU (ECM).

Parameter	Description
Enabled	<p><input type="checkbox"/> = Post-heat is disabled.</p> <p><input checked="" type="checkbox"/> = When the <i>Coolant Temperature</i> is below the configured <i>On</i> level, the <i>Pre-Heat</i> digital output is activated for the set <i>Duration</i> of time after cranking and before the set is considered available.</p>
On	Set the coolant temperature below which the pre-heat is activated.
Duration	Set the time delay during which the <i>Pre-Heat</i> digital output remains active after cranking and before the engine is considered available.



2.8.5.5 ECU (ECM) OPTIONS

The screenshot shows the 'ECU (ECM) Options' configuration window. It includes sections for:

- Engine Hours:** A checkbox for 'Module to Record Engine Hours'.
- DPF Regeneration Control:** A checkbox for 'Allow Non-Mission Regeneration'.
- Speed Switch:** An 'Enable' checkbox and a dropdown menu set to 'Default Dataset ECU'.
- ECU Wakeup:** An 'Enable' checkbox, a 'Periodic Wakeup Time' slider set to '1h', and a 'Coolant Measurement Persistence' checkbox.
- ECU (ECM) Startup Delay:** An 'Enable' checkbox and a 'Delay' slider set to '2s'.
- SPN Ignore List:** A table with 10 rows, each with an 'SPN' dropdown (values 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10) and an 'FMI' dropdown (values Any, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10).
- Miscellaneous:** A 'CAN source address (engine messages)' dropdown set to '17'.


Parameter	Description
Module to Record Engine Hours	When enabled, DSE module counts Engine Run Hours. When disabled, Engine ECU (ECM) provides Run Hours.
DPF Regeneration Control	Available for ECUs (ECM) which require the engine speed to drop during a manual regeneration cycle. During this time, the generator is not available to supply power and the under speed and under frequency alarms are not active.
Speed Switch	Defines the method of speed control over CANbus when supported by the ECU (ECM). Selection needs to match the ECU (ECM) calibration for the speed control method. Available speed control methods to choose from: CAN Open Increase Decrease CAN Open Speed Demand Default Dataset ECU ECU Analogue Absolute ECU Analogue Relative ECU CAN Open Analogue ECU Frequency Input ECU Increase Decrease Input
ECU Wakeup	<input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = When the engine is stopped, the DSE module sends a wakeup signal to the ECU (ECM) and keeps it powered up for 2 minutes to read the ECU (ECM) parameters. This is periodically repeated depending on the configured <i>Periodic Wakeup Time</i> .

Parameters continued overleaf...


Parameter	Description
Coolant Measurement Persistence	<p> NOTE: Available only when ECU Wakeup is enabled.</p> <p><input type="checkbox"/> = Option is disabled. <input checked="" type="checkbox"/> = The <i>Coolant Temperature</i> measurement is used for the <i>Coolant Temperature Control</i>.</p>
SPN Ignore List	<p>Choose the specific SPN for the module to ignore. The module allows the engine to keep running when the ignored SPN occurs; however, depending on the severity, the engine shuts down based on the ECU (ECM) calibration. This is used to mask certain indications or warnings on the ECU (ECM) and not display them on the DSE module.</p>
CAN Source Address (Engine Messages)	<p> NOTE: This is useful when the <i>Electronic Engine ECU's CAN Source Address</i> is different than its default address.</p> <p>Set the <i>CAN Source Address</i> for the DSE module over which other CANbus devices read the alarms.</p>

2.8.6 ECU (ECM) ALARMS

The *ECU Alarms* section is subdivided into smaller sections. Select the required section with the mouse.



2.8.6.1 ECU DATA FAIL



Parameter	Description
CAN Data Fail	Provides protection against failure of the ECU CAN data link. The alarm action list is as follows, see section entitled <i>Alarm Types</i> for more information: None Electrical Trip Shutdown Warning
Arming	Select when the <i>CAN ECU Data Fail</i> alarm is active. Options are as follows: Always: The alarm is active at anytime the CAN Link is lost From Safety On: Active only after the <i>Safety On</i> delay timer From Starting: Active only after the <i>Crank Relay</i> is energised Never: Alarm is disabled Engine Protection Activation: Active when the engine protections are activated
Activation Delay	The amount of time before the module activates the <i>CAN ECU Data Fail</i> after a failure.

2.8.6.2 DM1 SIGNALS

NOTE: This section is only available when the module is connected to an ECU.

NOTE: Configuration of parameters in this section only has effect when the ECU supports these features.

NOTE: Configuration of the *Alarm Action* in this section defines the DSE module response to the CAN message; however, the ECU still shuts down the engine depending on the alarm severity.

DM1 signals are messages from the CAN ECU. The following parameters allows configuration of how the DSE module responds to these messages.

The screenshot displays the 'DM1 Signals' configuration interface, which is organized into four sections: ECU Amber, ECU Red, ECU Malfunction, and ECU Protect. Each section contains three configuration parameters: 'Action', 'Arming', and 'Activation Delay'. The 'Action' parameter is a dropdown menu with options: None, Electrical Trip, Shutdown, or Warning. The 'Arming' parameter is a dropdown menu with options: Always, From Safety On, From Starting, or Never. The 'Activation Delay' parameter is a slider control with a '0s' label. Two callout boxes provide additional information: the first callout points to the 'Action' dropdown in the ECU Amber section, and the second callout points to the 'Arming' dropdown in the ECU Red section.

Signal Type	Action	Arming	Activation Delay
ECU Amber	Warning	Always	0s
ECU Red	Shutdown	From Safety On	0s
ECU Malfunction	Warning	Always	0s
ECU Protect	Warning	From Safety On	0s

2.8.6.3 ADVANCED

NOTE: This section is only available when the module is connected to an ECU.

NOTE: Configuration of parameters in this section only has effect when the ECU supports the features.

Allows configuration of selected additional CAN messages from the engine ECU.

Other Specific Signals

Water In Fuel

Action: Warning

Arming: Always

Activation Delay: 0s

Select the alarm action: None, Electrical Trip, Shutdown, or Warning

DPTC Filter

Enabled:

Action: Warning

Arming: From Safety On

Select when the alarm is active: Always, From Safety On, From Starting, Never.

HEST Active

Enabled:

Action: Warning

Arming: From Safety On

DEF Level

Enabled:

Action: Warning

Arming: From Safety On

Activation Delay: 0s

SCR Inducement

Enabled:

Action: Warning

Arming: From Safety On

Activation Delay: 0s

2.8.7 CRANK DISCONNECT

Crank disconnect settings are used to detect when the set fires during the starting sequence. As the set is cranked, the first parameter that passes its *crank disconnect* setting results in the cessation of the cranking signal.

Having more than one *crank disconnect* source allows for a much faster crank disconnect response leading to less wear on the engine and starter components, and provides added safety in case one source is lost, by a blown or tripped fuse for example.

Cranking

Options

Crank disconnect on oil pressure

Check oil pressure prior to starting

Crank Disconnect

Generator Frequency 21.0 Hz

Engine Speed 600 RPM

Oil Pressure 2.00 Bar

If *Check Oil Pressure Prior to Starting* is enabled, the cranking is not allowed if the oil pressure is not seen as being low. This is used as a *double check* that the engine is stopped before the starter is engaged.

Click and drag to change the setting.

Type the value or click the up and down arrows to change the settings

2.8.8 GAS ENGINE OPTIONS

NOTE: Only applicable when *Conventional Gas Engine Type* is selected.

Gas Engine Options

Gas Engine Timers


Choke Timer 2s

Gas On Delay 2s

Ignition Off Delay 2s


Parameter	Description
Choke Timer	Controls the amount of time that the Gas Choke output is active during the starting sequence.
Gas On Delay	Controls the amount of time between energising the Gas Ignition and energising the Fuel output. Used in the starting sequence to purge old gas from the engine.
Ignition Off Delay	Controls the amount of time between de-energising the Fuel output and de-energising the Gas Ignition output. Used in the stopping sequence to purge unburnt gas from the engine before it is stopped.

2.8.9 SPEED SENSING



Parameter	Description
Disable ECM Speed Sensing	<input type="checkbox"/> = An ECM is connected to the DSE module and being used for speed sensing. <input checked="" type="checkbox"/> = An ECM is connected to the DSE module but another form of speed sensing fitted to the DSE module is being used.
Magnetic Pickup Fitted	<p>NOTE: For specifications of the magnetic pickup input, refer to DSE Publication: 057-236 DSE6100MKII Operator Manual which is found on our website: www.deepseapl.com</p> <input type="checkbox"/> = Magnetic pickup device is not connected to the DSE module. <input checked="" type="checkbox"/> = A low impedance magnetic pickup device is connected to the DSE module to measure engine speed.
Flywheel Teeth	Define the number of pulses which are counted by the speed sensing device in each engine revolution.
Loss of Sensing Signal	If the speed sensing signal is lost during engine running (or not present during cranking when <i>Multiple Engage Attempts</i> is enabled), an alarm is generated: <i>Shutdown:</i> The engine is removed from load and is immediately stopped. <i>Warning:</i> The engine continues to run, however a warning alarm is raised.

2.8.10 SPEED SETTINGS



Parameters detailed overleaf...

2.8.10.1 UNDER SPEED

Parameter	Description
Under Speed Alarm	<input type="checkbox"/> = <i>Under Speed</i> alarm is disabled <input checked="" type="checkbox"/> = Under Speed gives a <i>Shutdown</i> alarm in the event of the engine speed falling below the configured <i>Under Speed Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Underspeed Alarm Trip</i> value is adjustable to suit user requirements.

2.8.10.2 OVER SPEED

Parameter	Description
Over Speed Pre-Alarm	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Over Speed gives a warning alarm in the event of the engine speed rising above the configured <i>Over Speed Pre-Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Warning</i> is automatically reset when the engine speed falls below the configured <i>Return</i> level. The <i>Over Speed Pre-Alarm Trip</i> value is adjustable to suit user requirements.
Over Speed Alarm	<input type="checkbox"/> = Alarm is disabled <input checked="" type="checkbox"/> = Over Speed gives a <i>Shutdown</i> alarm in the event of the engine speed rising above the configured <i>Over Speed Alarm Trip</i> value for longer than the <i>Activation Delay</i> . The <i>Over Speed Alarm Trip</i> value is adjustable to suit user requirements.
Overshoot Delay	To prevent spurious overspeed alarms at engine start up, the module includes configurable <i>Overspeed Overshoot</i> protection. This allows the engine speed to 'overshoot' the Overspeed setting during the starting process for a short time. Rather than 'inhibiting' the Overspeed alarms, the levels are temporarily raised by the DSE module's default <i>Overspeed Overshoot %</i> for the duration of the <i>Overspeed Overshoot</i> delay from starting.

2.8.11 PLANT BATTERY

The screenshot shows the 'Plant Battery' configuration window, divided into three main sections: Voltage Alarms, Charge Alternator Alarm, and Start On Low Battery. Each section contains various settings with interactive controls like checkboxes, sliders, and numeric input fields.

Voltage Alarms

- Undervolts** (checked):
 - Warning: 10.0 V DC (slider)
 - Return: 10.5 V DC (slider)
 - Delay: 1m (slider)
- Overvolts** (checked):
 - Return: 29.5 V DC (slider)
 - Warning: 30.0 V DC (slider)
 - Delay: 1m (slider)

Charge Alternator Alarm

- Use Module for Charge Alternator:
- Shutdown (checked):
 - Trip: 4.0 V DC (slider)
 - Delay: 5s (slider)
- Warning (checked):
 - Trip: 6.0 V DC (slider)
 - Delay: 5s (slider)

Start On Low Battery

- Enable:
- Start On Load:
- Threshold: 18.0 V DC (slider)
- Engine Run Time: 1h (slider)
- Delay: 5s (slider)

Callouts:

- Left callout: 'Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled.'
- Top right callout: 'Click and drag to change the setting.'
- Bottom right callout: 'Type the value or click the up and down arrows to change the settings'

Parameters described overleaf...

2.8.11.1 PLANT BATTERY VOLTAGE ALARMS

Parameter	Description
Plant Battery Undervolts IEEE 37.2 -27 DC Undervoltage Relay	The alarm activates when the battery voltage drops below the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage rises above the configured <i>Return</i> level, the alarm is de-activated.
Plant Battery Overvolts IEEE 37.2 -59 DC Overvoltage Relay	The alarm activates when the battery voltage rises above the configured <i>Pre-Alarm</i> level for the configured <i>Delay</i> time. When the battery voltage drops below the configured <i>Return</i> level, the alarm is de-activated.

2.8.11.2 CHARGE ALTERNATOR ALARM

Parameter	Description
Use Module For Charge Alternator	<input type="checkbox"/> = .When CAN engine selected, the charge alternator is controlled by the engine ECU (ECM). <input checked="" type="checkbox"/> =When CAN engine selected, the charge alternator is controlled by the DSE module.
Charge Alternator Shutdown	<input type="checkbox"/> = The <i>Shutdown</i> alarm is disabled. <input checked="" type="checkbox"/> = The <i>shutdown</i> alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.
Charge Alternator Pre-Alarm	<input type="checkbox"/> = The <i>Warning</i> alarm is disabled.. <input checked="" type="checkbox"/> = The <i>Warning</i> alarm activates when the charge alternator voltage falls below the configured <i>Trip</i> level for the configured <i>Delay</i> time.

2.8.11.3 START ON LOW BATTERY

Parameter	Description
Start on Low Battery	<input type="checkbox"/> = Start on Low Battery is disabled. <input checked="" type="checkbox"/> = Select to enable autostart upon the battery voltage falling below the <i>Threshold</i> level for longer than the <i>Start Delay</i> time. The engine starts and run for the specified <i>Engine Run Time</i> . This occurs only if the module is in AUTO mode.
Start On Load	<input type="checkbox"/> = Run the generator <i>Off Load</i> . <input checked="" type="checkbox"/> = Run the generator <i>On Load</i> .

2.9 MAINTENANCE ALARM

The screenshot displays the 'Maintenance Alarm' configuration window, which is divided into three sections: Maintenance Alarm 1, Maintenance Alarm 2, and Maintenance Alarm 3. Each section contains the following fields:

- Enable:** A checkbox to activate or deactivate the alarm.
- Description:** A text field for the alarm's name.
- Action:** A dropdown menu to select the response (Warning or Shutdown).
- Engine run hours:** A numeric input field with a unit selector (hrs).
- Enable alarm on due date:** A checkbox to allow time-based triggering.
- Maintenance interval:** A numeric input field with a unit selector (months).

Callouts provide the following information:

- Callout 1:** Points to the 'Enable' checkbox for Maintenance Alarm 1, stating: "Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled."
- Callout 2:** Points to the 'Action' dropdown for Maintenance Alarm 1, stating: "Select the type of action when the maintenance alarm occurs. Options are: *Warning*, or *Shutdown*".
- Callout 3:** Points to the 'Engine run hours' field for Maintenance Alarm 2, stating: "Maintenance Alarm occurs when the engine has run for the specified number of hours."
- Callout 4:** Points to the 'Enable alarm on due date' checkbox for Maintenance Alarm 2, stating: "Maintenance alarm occurs on a time basis, even when the engine hours did not increase."

There are two ways to reset the maintenance alarm:

- 1) Activate a digital input configured to "Maintenance Reset Alarm".
- 2) Use the SCADA | Maintenance | Maintenance Alarm section of this PC Software.

2.10 SCHEDULER

The scheduler is used to automatically start the set at a configured day and time and run it for the configured duration of hours.

The generator is made to run *on load* or *off load* depending upon the configuration :

Scheduler

Exercise Scheduler

Enabled


Schedule Period Weekly

Week	Day	Run Mode	Start Time	Duration	
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear
▼	Monday ▼	Off Load ▼	▲ 00:00 ▼	▲ 00:00 ▼	Clear

Function	Description
Enabled	<input type="checkbox"/> = Scheduled runs are disabled <input checked="" type="checkbox"/> = Enables the Scheduler
Schedule Period	Determines the repeat interval for the scheduled run. Options available are: Weekly, Monthly
Run Mode	Determines the loading state mode of the generator when running on schedule <i>Auto Start Inhibit:</i> the generator is prevented from running in <i>Auto</i> mode. <i>Off Load:</i> The module runs the generator on schedule with the breaker open <i>On Load:</i> The module runs the generator on schedule and closes the breaker
Week	Specifies the week of the month, on which the scheduled run takes place
Day	Specifies the day of week, on which the scheduled run takes place
Start Time	Determines at what time of day the scheduled run starts
Duration	Determines the time duration in hours for the scheduled run
Clear	Resets the values for the Day, Start Time and Duration to defaults


2.11 DISPLAY STRINGS

The *Display Strings* section is subdivided into smaller sections. Select the required section with the mouse.



2.11.1 SUPPORT STRINGS

The module display is able to accommodate for up to six support pages. Information entered in the below page appear on the module LCD for the end-user.

A large screenshot of the 'Support Strings' configuration page. The page is titled 'Support Strings' and contains six sections, each labeled 'Page 1' through 'Page 6'. Each page section contains three lines of text input, labeled 'Line 1', 'Line 2', and 'Line 3'. The input fields are empty.


2.11.2 USER DEFINED STRINGS

The module display is able to accommodate for up to two *User Defined Strings* pages. Information entered in the below page appear on the module LCD for the end-user.

The image shows a screenshot of a configuration interface titled "User Defined Strings". It is divided into two sections: "Page 1" and "Page 2". Each section contains three horizontal input fields labeled "Line 1", "Line 2", and "Line 3". The fields are empty, indicating that no user-defined strings have been entered yet.


2.12 CONFIGURABLE CAN INSTRUMENTATION

The *Configurable CAN Instrumentation* section is subdivided into smaller sections. Select the required section with the mouse.



2.12.1 RECEIVED INSTRUMENTATION (1-10)


This feature allows for up to ten custom engine CAN instrumentation items to be decoded from CAN messages on the connected ECU port.



Parameter	Description
Enabled	<p>NOTE: The CAN instrumentation must already be available on the CAN bus. There is no request for a non-standard instrumentation.</p> <p><input type="checkbox"/> = The CAN instrumentation is disabled. <input checked="" type="checkbox"/> = The CAN instrumentation is enabled. Reading depends upon the message availability on the bus.</p>
On Module	<p>NOTE: The CAN instrumentation is always available on the Scada, Data Logging, PLC as long as at least one CAN instrumentation is enabled. The CAN instrumentation is shown on the DSE61xx MKII module's display when the <i>On Module</i> is enabled.</p> <p><input type="checkbox"/> = The CAN instrumentation is not displayed on the DSE614xx MKII module. <input checked="" type="checkbox"/> = The CAN instrumentation is displayed on the DSE61xx MKII module.</p>
Description	Provide a description for the CAN instrumentation. This description is only shown in the Scada.
Details	Click on Details to set the <i>Message Decoding CAN</i> options.


Click on *Details...* to set the *Message Decoding* parameters.

2.12.1.1 MESSAGE IDENTIFICATION




Parameter	Description
Message Type	Select the required message type: 11 Bit message identifier for standard CAN 29 Bit message identifier for extended CAN
Message ID	CAN message ID
Enabled	<input type="checkbox"/> = Timeout is disabled <input checked="" type="checkbox"/> = Timeout is enabled
Timeout	It indicates how often the messages are expected to be seen on the CAN bus. If no new instrumentation is seen beyond the timeout period, the calculated instrumentation value changes to a 'bad data' sentinel value.

2.12.1.2 DATA STRUCTURE



Parameter	Description
Byte Order	Select the <i>Byte Order</i> Big Endian the bytes on the bus are sent from the Most Significant Byte to the Least Significant Byte. Little Endian the bytes on the bus are sent from the Least Significant Byte to the Most Significant Byte.
Offset Byte	Set the start position Byte
Offset Bit	Set the start position Bit
Length (Bits)	Data length 1-32 bits
Signed Value	<input type="checkbox"/> = Unsigned value <input checked="" type="checkbox"/> = Signed value


2.12.1.3 DISPLAY




Parameters detailed overleaf...


Parameter	Description
Decimal Places	Display the decimal point. 0 represents 0 scaling factor, 1 represents 0.1 scaling factor, -1 represents 10 multiplier.
Suffix	Unit display (example: m ³ /hr)
Smallest Raw Value	The smallest data sent over the CAN bus before the transformations (decimal places).
Maps To	The output format after all transformations including decimal point shift) as to be shown on the module screen, or SCADA, in data log file, etc.
Largest Raw Value	The largest data sent over the CAN bus before the transformations (decimal places).
Maps To	The output format after all transformations including decimal point shift) as to be shown on the module screen, or SCADA, in data log file, etc.


2.12.1.4 TEST



Parameter	Description
Test Raw Value	<p> NOTE: The Test Raw Value is not saved in the configuration, this is only to check the displayed value.</p> <p>This is a test case to check the representation of the <i>Raw Value</i> when they are complicated. <i>Test Raw Value</i> is the value read from the CAN bus before the transformation</p>
Displayed Value	The <i>Test Raw Values</i> 's represented value as to be shown on the DSE61xx MKII's screen, or in the Scada.

2.12.2 RECEIVED INSTRUMENTATION (11-30)

 **NOTE: The *Received Instrumentation (11-30)* only have the default Description string. Description cannot be configured to the *Received Instrumentation (11-30)*.**

 **NOTE: The *Message Decoding Details* parameters of the *Received Instrumentation(11-30)* are exactly the same as the *Received Intrumentation (1-10)*. Please refer to the previous subsection for the *Message Decoding Details*.**

Received Instrumentation (11-30)				
Instrumentation Configuration				
	Enabled	On Module	Description	
11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 11	Details...
12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 12	Details...
13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 13	Details...
14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 14	Details...
15	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 15	Details...
16	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 16	Details...
17	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 17	Details...
18	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 18	Details...
19	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 19	Details...
20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 20	Details...
21	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 21	Details...
22	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 22	Details...
23	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 23	Details...
24	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 24	Details...
25	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 25	Details...
26	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 26	Details...
27	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 27	Details...
28	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 28	Details...
29	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 29	Details...
30	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Configurable CAN Instrument 30	Details...

2.12.3 TRANSMITTED INSTRUMENTATION


The DSE61xx MKII module allows transmitting up to five instruments over the CANbus on the ECU port by specifying the source address (message ID) of the selected Instrument.

Transmitted Instrumentation			
Instrumentation Configuration			
	Enabled	Source	
1	<input checked="" type="checkbox"/>	Generator Total Power	Details...
2	<input checked="" type="checkbox"/>	Generator Volts (L1-N)	Details...
3	<input checked="" type="checkbox"/>	Generator Current L1	Details...
4	<input checked="" type="checkbox"/>	Generator Frequency	Details...
5	<input checked="" type="checkbox"/>	Configurable CAN Instrument 1	Details...

Parameters detailed overleaf...


Parameter	Description
Enabled	<input type="checkbox"/> = The Transmit CAN instrumentation is disabled. <input checked="" type="checkbox"/> = The Transmit CAN instrumentation is enabled.
Source	Select the instrument to be created over the CAN.
Details	Click on Details to set the <i>Message Encoding CAN</i> options.

2.12.3.1 MESSAGE IDENTIFICATION



Parameter	Description
Message Type	Select the required message type to transmit: 11 Bit message identifier for standard CAN 29 Bit message identifier for extended CAN
Message ID	CAN message ID
Transmit Rate	The rate at which the <i>CAN Instrument</i> is transmitted over the CANbus.

2.12.3.2 DATA STRUCTURE



Parameter	Description
Byte Order	Select the <i>Byte Order</i> Big Endian the bytes on the bus are sent from the Most Significant Byte to the Least Significant Byte. Little Endian the bytes on the bus are sent from the Least Significant Byte to the Most Significant Byte.
Offset Byte	Set the start position Byte
Offset Bit	Set the start position Bit
Length (Bits)	Data length 1-32 bits
Signed Value	<input type="checkbox"/> = Transmit unsigned value <input checked="" type="checkbox"/> = Transmit signed value

Continued Overleaf..

2.12.3.3 MAPPING

Mapping

Smallest Source Value Maps To

Largest Source Value Maps To


Parameter	Description
Smallest Source Value	The smallest instrument value before being sent over the CAN bus.
Maps To	The transmitted format for the <i>Smallest Source Value</i> .
Largest Source Value	The largest instrument value before being sent over the CAN bus.
Maps To	The transmitted format for the <i>Largest Source Value</i> .

2.12.3.4 TEST

Test

Source Value

Mapped Value 0

Parameter	Description
Source Value	<p> NOTE: The <i>Source Value</i> is not transmitted over the CANbus, this is only to check the encoded value.</p> <p>This is a test case to check the representation of the <i>Source Value</i> when they are complicated. <i>Source Value</i> is the instrument value before being encoded.</p>
Mapped Value	The <i>Mapped Value</i> represents the transmitted <i>Source value</i> .

2.12.4 CONFIGURABLE CAN INSTRUMENTATION EXPORT/IMPORT

This feature is used to import the *Configurable CAN Instrumentation* settings in another DSE61xx MKII module.


Parameter	Description
Export	This allows the configuration settings of all Configurable CAN Instrumentation (Received & Transmitted) into one XML file.
Import	This allows to import an existing configuration settings of all Configurable CAN Instrumentation saved in XML format.

2.13 ALTERNATIVE CONFIGURATION

An Alternative Configuration is provided to allow the system designer to cater for different AC requirements utilising the same generator system. Typically this feature is used by Rental Set Manufacturers where the set is capable of being operated at (for instance) 120V 50Hz and 240V 50Hz using a selector switch.

The Alternative Configuration is selected using either:

- Configuration Suite Software (Selection for 'Default Configuration')
- Module Front Panel Editor
- Via external signal to the module input configured to "Alternative Configuration" select.




2.13.1 ALTERNATIVE CONFIGURATION OPTIONS



2.13.2 ALTERNATIVE CONFIGURATION OPTIONS

The Alternative Configurations Editor allows for editing of the parameters that are to be changed when an Alternative Configuration is selected.




Alternative configuration options contain a subset of the main configuration. The adjustable parameters are not discussed here as they are identical to the main configuration options :




Configuration menus for the *Alternative Configuration*. For information about the configuration items within this section, refer to their description in the 'main' configuration.

2.14 EXPANSION

 **NOTE: A maximum of two (2) expansion units are connected to the DSE6100 MKII series of controllers.**


The *Expansion* page is subdivided into smaller sections.
Select the required section with the mouse.



See overleaf for description of the different expansion modules.

2.14.1 DSE2130 INPUT MODULES

Select the DSENet ID of the input expansion you wish to configure. The ID of the expansion input module is set by rotary decimal switch accessible under the removable cover of the device.



The following is then shown:

DSENet ID 0

2130 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Shutdown

2130 Expansion Inputs

[Analogue Input Configuration](#)

[Analogue Inputs](#)

[Digital Inputs](#)

Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled.

Select the alarm type of the *link lost alarm*. This alarm takes action if the expansion module is not detected by the host module.

Select which of the expansion inputs you wish to configure.

2.14.1.1 DIGITAL INPUTS (A-D)

Digital Inputs A - D

Digital Input A

Function User Configured

Polarity Close to Activate

Action Shutdown

Arming Never

LCD Display 2130 ID0 Digital Input A

Activation Delay 0s

Select the required function of the input and whether it is *open* or *close to activate*.

Select the required alarm type of the input and when it is active.

Type the text that is to appear on the module's display when the alarm is active.

Gives a delay upon activation of the input to allow the input to be used as a level switch for example.

2.14.1.2 ANALOGUE INPUTS (E-H)

Configured as an Analogue Input

Flexible Sensor E

Sensor Description

Sensor Type: Pressure Sensor
 Sensor Name: Flexible Sensor

Input Type

VDO 10 Bar Edit... *Callout: Edit the sensor curve if required.*

Sensor Alarms

Alarm Arming: Always

Low Alarm Enable: *Callout: Click and drag to change the setting.*

Low Alarm Action: Shutdown

Low Alarm: 1.03 Bar *Callout: Click to enable or disable the option. The relevant values below appears greyed out if the alarm is disabled.*

Low Pre-alarm Enable:

Low Pre-alarm Trip: 1.17 Bar

Low Pre-alarm Return: 1.24 Bar

Low Alarm String: Flexible Sensor Low

High Pre-alarm Enable: *Callout: Type the value or click the up and down arrows to change the settings.*

High Pre-alarm Return: 1.40 Bar

High Pre-alarm Trip: 1.50 Bar

High Alarm Enable:

High Alarm Action: Shutdown

High Alarm: 1.60 Bar

High Alarm String: Flexible Sensor High

Configured as a Digital Input

Analogue Inputs E - H

Analogue Input E (Digital)

Function: User Configured *Callout: Select the required function of the input and whether it is open or close to activate.*

Polarity: Close to Activate

Action: Shutdown *Callout: Select the required alarm type of the input and when it is active.*


Arming: Never

LCD Display: 2130 ID0 Digital Input E *Callout: Type the text that is to appear on the module's display when the alarm is active.*

Activation Delay: 0s *Callout: Gives a delay upon activation of the input to allow the input to be used as a liquid level switch for example.*

2.14.2 DSE2157 RELAY MODULES

Select the DSENet ID of the relay expansion you wish to configure. The ID of the relay board is set by rotary decimal switch accessible under the removable cover of the device.



The following is then shown:

DSENet ID 0

2157 Enable

Expansion Enabled

Link Lost Alarm Action Shutdown

Relay Outputs (Normally Open)

	Source	Polarity
A	Audible Alarm	Energise
B	System In Auto Mode	Energise
C	Not Used	Energise
D	Not Used	Energise

Relay Outputs (Changeover)

	Source	Polarity
E	Not Used	Energise
F	Not Used	Energise
G	Not Used	Energise
H	Not Used	Energise

Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled.

Select the alarm type of the *link lost alarm*. This alarm takes action if the expansion module is not detected by the host module.

Select the output source and the polarity required. For example this output *energises* when the module is in the *Auto* mode.

2.14.3 DSE2548 LED EXPANSION

Select the DSENet ID of the LED expansion you wish to configure. The ID of the Annunciator is set by rotary decimal switch accessible on the back of the device.



The following is then shown:

DSENet ID 0

2548 Expansion Enable

Expansion Enabled

Link Lost Alarm Action Shutdown

Sounder Configuration

Follow main unit

Sounder enabled

LED Indicators

A	Not Used	Lit
B	Not Used	Lit
C	Not Used	Lit
D	Not Used	Lit
E	Not Used	Lit
F	Not Used	Lit
G	Not Used	Lit
H	Not Used	Lit

Annunciator Insert Card

Click to enable or disable the option. The relevant values below appears *greyed out* if the alarm is disabled.

Select the alarm type of the *link lost alarm*. This alarm takes action if the expansion module is not detected by the host module.

- If the *Mute / Lamp Test* button is pressed, other DSE2548 modules configured to *Follow Main Unit* and the host module also perform *Lamp Test / Mute* their alarm and vice-versa. - If the *Mute / Lamp Test* button is pressed, other DSE2548 modules and the host module does not respond to this.


Enable or disable the expansion module's internal sounder.

Select the configuration for the LED. For instance this LED is configured to be *Unlit* when in Auto mode. Hence this is a *Not in Auto* LED.


3 SCADA

SCADA stands for **S**upervisory **C**ontrol **A**nd **D**ata **A**cquisition and is provided both as a service tool and also as a means of monitoring / controlling the generator set.


As a service tool, the SCADA pages are to check the operation of the controller's inputs and outputs as well as checking the generators operating parameters.



When connection is made...



The SCADA page is subdivided into smaller sections. Select the required section with the mouse.



3.1 MIMIC

This screen provides a mimic of the control module and allows the operator to change the control mode of the module.



Hint : Buttons may not operate if this has been locked out by the *Access Permissions* security feature of the Configuration Suite Software. Refer to the system supplier for details.

Click the mimic buttons to control the module remotely

3.2 LANGUAGES

The screenshot shows a 'Languages' control panel. It features a dropdown menu for 'Current Module Language' currently set to 'English'. Below it is a 'To upload' section with a file selection dropdown showing '<No suitable language files>'. An 'Upload Now' button is located at the bottom. Callouts provide the following information:

- 'Current language in the module.' points to the 'Current Module Language' dropdown.
- 'Select new language' points to the 'To upload' file selection dropdown.
- 'Click to send the new language to the module' points to the 'Upload Now' button.

3.3 DIGITAL INPUTS

The screenshot displays the 'Digital Inputs' panel with a table of inputs and their status:

	Active	Open / Closed
A Digital Input A	●	⏏
B Lamp Test	●	⏏
C Alarm Mute	●	⏏
D Remote Start On Load	●	⏏
E Digital Input E	●	⏏
F Smoke Limiting	●	⏏
Emergency Stop		🛑

Callouts provide the following information:

- 'Shows if the digital input is active or not.' points to the 'Active' column of green circles.
- 'State of the input (open or closed to battery negative)' points to the 'Open / Closed' column of switch icons.

3.4 DIGITAL OUTPUTS

The screenshot displays the 'Digital Outputs' panel with a table of outputs and their status:

	Active	Open / Closed
A Fuel Relay	●	⏏
B Start Relay	●	⏏
C Light Output 1	●	⏏
D Light Output 2	●	⏏
E Light Output 3	●	⏏
F Light Output 4	●	⏏

Callouts provide the following information:


- 'Shows if the output channel is active or not.' points to the 'Active' column of green circles.
- 'State of the output (open or closed)' points to the 'Open / Closed' column of switch icons.

3.5 MAINS



= Only available on DSE6120 MKII AMF Modules

The *Mains* section is subdivided into smaller sections. Select the required section with the mouse.



3.5.1 FREQUENCY, VOLTAGES AND CURRENT

Shows the modules measurements of the mains supply (6120 MKII only).

Mains

Frequency

50.4 Hz

Phase To Neutral Voltages

L1 - N	L2 - N	L3 - N
228.7 V	228.6 V	228.6 V

Phase To Phase Voltages

L1 - L2	L2 - L3	L3 - L1
395.4 V	396.6 V	394.9 V

Current

L1	L2	L3
----	----	----

Mains current is displayed when the CTs are placed in the *load* and the mains is on load.


3.5.2 POWER

Shows the modules measurements of the mains supply power (6020 MKII only).

Power				
Watts				
	L1	L2	L3	Total
	3.0 kW	3.0 kW	3.0 kW	9.0 kW
VA				
	L1	L2	L3	Total
	10.0 kVA	10.0 kVA	10.0 kVA	30.0 kVA
VAr				
	L1	L2	L3	Total
	8.0 kVAr	8.0 kVAr	8.0 kVAr	24.0 kVAr
Power factor				
	L1	L2	L3	Average
Lag	0.32	Lag 0.32	Lag 0.31	Lag 0.30
Accumulated Power				
	kWh	kVAh	kVArh	
	107.7 kWh	174.2 kVAh	75.0 kVArh	

3.6 GENERATOR

The *Generator* section is subdivided into smaller sections. Select the required section with the mouse.



3.6.1 FREQUENCY, VOLTAGES AND CURRENT

Shows the modules measurements of the generator supply.

A screenshot of a SCADA monitoring interface for a generator. The interface is organized into several sections, each with a blue header. The 'Generator' section is at the top. Below it are sections for 'Frequency', 'Phase to Neutral Voltages', 'Phase to Phase Voltages', and 'Current'. Each section displays real-time measurements for three phases (L1, L2, L3).


Generator			
Frequency			
49.9 Hz			
Phase to Neutral Voltages			
L1 - N	L2 - N	L3 - N	
229.6 v	229.7 v	229.2 v	
Phase to Phase Voltages			
L1 - L2	L2 - L3	L3 - L1	
397.8 v	396.9 v	398.1 v	
Current			
L1	L2	L3	
180.0 A	181.0 A	182.0 A	

3.6.2 POWER

Power				
Watts				
	L1	L2	L3	Total
	33.0 kW	34.0 kW	33.0 kW	100.0 kW
VA				
	L1	L2	L3	Total
	41.0 kVA	42.0 kVA	42.0 kVA	125.0 kVA
VAr				
	L1	L2	L3	Total
	24.0 kVAr	24.0 kVAr	24.0 kVAr	72.0 kVAr
Power Factor				
	L1	L2	L3	Average
Lag	0.80	Lag 0.80	Lag 0.79	Lag 0.80
Accumulated Power				
	kWh	kVAh	kVArh	
	15.5 kWh	19.2 kVAh	10.7 kVArh	

3.7 ENGINE

Shows the modules measurements of the engine parameters.



3.8 FLEXIBLE SENSOR

Shows the modules measurements of the flexible sensors parameters.

Flexible Sensor

This page is used when Analogue Inputs are configured as Flexible Sensors

Flexible Sensor A

Not Used

Flexible Sensor B

Not Used

Flexible Sensor C

Percentage Sensor

Flexible Sensor
43 %

Flexible Sensor D

Pressure Sensor

Flexible Sensor
2.75Bar, 39.9 PSI, 275 kPa


3.9 CONFIGURABLE CAN INSTRUMENTATION

Shows the module's readings of the configured *CAN Instrumentation*. This is only available if the module is configured for *Configurable CAN Instrumentation*, the *Enhanced Canbus* option is enabled, and the message is available over the relevant configured CAN bus.

Configurable CAN Instrumentation		
Configurable CAN Instrumentation		
1	Longitude - VP	210.0072902
2	Engine Oil Pressure - EFL_P1	124 kPa
3	Latitude - VP	1.0036625
4	Engine Coolant Pressure - EFL_P1	234 kPa
5	Engine Fuel Pressure - EFL_P1	0 kPa
6	Engine Hours - HOURS	1000.0 hr
7	Engine Oil Temperature 1 - ET1	84.37042 deg C
8	Engine Coolant Temperature - ET1	55 deg C
9	Engine Fuel Rate - LFE	10.00 L/h
10	Electrical Potencial Plnp - VEP1	0.00 V

3.10 ALARMS

Shows any present alarm conditions.




3.11 ENGINE ALARMS

The *Engine Alarms* page is subdivided into smaller sections. Select the required section with the mouse.




3.11.1 CURRENT ENGINE ALARMS

Shows the current engine alarms.



3.11.2 PREVIOUS ENGINE ALARMS

Shows the previous engine alarms.




3.12 STATUS

Shows the module's current status.

Status	
Supervisor State Running On Load	Software Version 1.0
Engine/Generator State Running	Module ID 218DDA17D
Mains Detection State [Empty]	Mode 
Load Switching State Closed To Generator	
Heater Fitted [Empty]	

3.13 EVENT LOG

Shows the contents of the module's event log.



The screenshot displays a software interface titled "Event Log". It features a table with the following data:

#	Date	Time	Hours Run	Event	Details
1	28/03/2013	12:01	0:00	Shutdown	Emergency Stop
2	28/03/2013	11:58	0:00	Restart	Power Up
3	28/03/2013	11:54	0:00	Shutdown	Oil Pressure Sensor Open Circuit
4	28/03/2013	11:54	0:00	Restart	Power Up

Below the table, there is a large empty rectangular area. At the bottom of the interface, a status bar displays "User: Admin".

3.14 ENHANCED CANBUS

Shows the module's readings of enhanced Canbus parameters. This is only available if the module is configured for CAN communication and the *Enhanced Canbus* option is enabled.




3.15 MAINTENANCE

The *Maintenance* section is subdivided into smaller sections. Select the required section with the mouse.




3.15.1 RECALIBRATE TRANSDUCERS

Allows the recalibration of the flexible sensors (when enabled in the module configuration).




3.15.2 EXPANSION CALIBRATION

This section allows the analogue sensor inputs of the DSE2130 input expansion modules to be calibrated to remove inaccuracies caused by the tolerance of the sensor devices. While the engine is running, the instruments are calibrated and reference needs to be made to a third party accurate sensing device to ensure accurate recalibration.



3.15.3 HOURS RUN AND NUMBER OF STARTS

This section allows the Hours Run and Number of Starts to be customised on the controller. Typically, this is used when fitting a new controller to an older generator so that the controller display matches the amount of work previously done by the system.



Type the value or click the up and down arrows to change the settings

Click to perform the adjustment in the module. Note that this is not visible on the module itself. It is included in the PC SCADA for diagnostic purposes.

3.15.4 MAINTENANCE ALARM RESET

Three maintenance alarms active in the control module. Each is reset individually.

The screenshot displays a 'Maintenance Alarm Reset' window with three distinct sections for Maintenance Alarm 1, Maintenance Alarm 2, and Maintenance Alarm 3. Each section contains the following information:

- Maintenance Alarm 1:** Running Time Until Next Maintenance: 100:00; Date Of Next Maintenance: (blank).
- Maintenance Alarm 2:** Running Time Until Next Maintenance: 60:00; Date Of Next Maintenance: 15/02/2000 01:32:49.
- Maintenance Alarm 3:** Running Time Until Next Maintenance: 550:00; Date Of Next Maintenance: 16/07/2000 01:32:49.

Each section includes a 'Reset' button and a note: 'Press reset to schedule next maintenance, based upon module's maintenance configuration.' A callout box points to the 'Reset' button of Maintenance Alarm 2, containing the text: 'Reset the maintenance alarm based upon the module's configuration.'

3.15.5 DPF REGENERATION


The DPF Forced Regeneration is controlled when the Electronic Engine supports the Non-mission DPF Regeneration.

The screenshot shows the 'DPF Regeneration' window. It features a 'DPF Auto Regen Inhibit' checkbox which is checked. Below this is a button labeled 'DPF Forced Regeneration'. A callout box points to this button with the text: 'Click to start the DPF Regeneration Manually'.

3.15.6 MODULE PIN

NOTE : If the PIN is lost or forgotten, it is no more possible to access the module!

Allows a PIN (Personal Identification Number) to be set in the controller. This PIN must be entered to either access the front panel configuration editor or before a configuration file is sent to the controller from the PC software.



3.15.7 DATE AND TIME

This section allows the day and time to be set and changed on the controller.

The screenshot displays a web-based configuration interface for the Date and Time settings. It is organized into four main sections:

- Date and Time**: The top section, which contains the current module date and time.
- Module Date**: A field displaying the current date as 28/03/2013.
- Module Time**: A field displaying the current time as 12:17:00.
- Set Date and Time**: A section for manual configuration, featuring two dropdown menus for Date (set to 28/03/2013) and Time (set to 12:17:00), and a 'Set' button below them.
- Set to PC Time**: A section for synchronizing the module with the PC, showing the PC's current Date (28/03/2013) and Time (12:16:44), and a 'Set to PC Time' button.

Callouts provide the following instructions:

- Display of the module's current date and time (pointing to the Module Date field).
- Type the new date / time or click the up and down arrows to change the settings (pointing to the Date and Time dropdown menus).
- Click Set to adjust the module to the selected date/time. (pointing to the Set button).
- Click Set to adjust the module to the date/time that the PC is set to. (pointing to the Set to PC Time button).

3.15.8 ACCUMULATED INSTRUMENTATION

Allows the user to view or change the module's accumulated instrumentation.

The screenshot shows the 'Accumulated Instrumentation' interface with three sections: kWh, kVAh, and kVArh. Each section displays a current value and a control panel with a numeric input field and a 'Set' button. A 'Reset' section at the bottom contains a 'Reset all values to zero' button. Callouts provide instructions: 'Display of the module's current value for the parameter.' points to the kWh value; 'Type the new value or click the up and down arrows to change the settings.' points to the kWh control panel; 'Click Set to adjust the module to the selected value.' points to the Set button in the kVAh section; and 'Click to reset all the accumulated instrumentation counters to zero.' points to the Reset button.

3.15.9 LCD CONTRAST


The LCD Contrast section allows the adjustment of the module's display contrast level. This is useful when the contrast is configured through the Front Panel Editor and set to a level where the display is no longer visible.

The screenshot shows the 'LCD Contrast' interface. It features a slider control for 'LCD Contrast' with a value of 15. A 'Set' button is located to the right of the slider. A callout box explains: 'Move the slider to adjust the LCD Contrast for the module display. The new value is written to the controller when the Set button is clicked.'

3.16 DATA LOG

Allows viewing of the module datalog (if configured).

NOTE : *Data Logging* is a 'live' function – Maximum 8hrs duration is shown so long as the PC is left connected to the controller.



3.17 EXPANSION

Expansion

- [2130 Input Modules](#)
- [2157 Relay Modules](#)
- [2548 Annunciator Modules](#)

Allows monitoring of the controller's expansion modules (if fitted)





For example:

Expansion Inputs

Communications

Communications OK ●

Inputs

	Active	Open / Closed
A 2130 Expansion Module ID1 Digital Input A	●	
B 2130 Expansion Module ID1 Digital Input B	●	
C 2130 Expansion Module ID1 Digital Input C	●	
D 2130 ID1 Digital Input D	●	
E <i>Not configured</i>		
F <i>Not configured</i>		
G <i>Not configured</i>		
H <i>Not configured</i>		

4 ALARM TYPES

The protection included with the DSE control modules provides increasing levels of notification, depending upon the severity of the situation:

Alarm type	Description
Indication	No audible alarm or common warning signal occurs. <i>Indication</i> alarms are only used to illuminate indicators or to activate outputs.
Warning	Audible alarm and common alarm signal is generated. The set continues to run. <i>Warning alarms</i> are used to draw the operator's attention to a minor issue or to a problem that may escalate to an Electrical Trip or Shutdown Alarm if left untreated.
Electrical Trip	Audible alarm and common alarm signal is generated. The set is taken off load and the cooling timer begins, after which the set is stopped. <i>Electrical Trip alarms</i> are series issues that require the set to be taken off load. As the name implies, this is often electrical faults that occur 'after' the load breaker. The set is allowed to cool before stopping.
Shutdown	Audible alarm and common alarm signal is generated. The set is taken off load and immediately stopped. <i>Shutdown alarms</i> are serious issues that demand immediate stopping of the generator. For instance Emergency Stop or Overspeed alarms require immediate shutdown.

This Page Intentionally Blank

This Page Intentionally Blank